

CONTENTS

| DESCRIPTION | PAGE # |
|--|--------|
| 1. MAIN PART OF THE MACHINE | 1 |
| A. For Supra 618II | 1 |
| B. For Supra 618AHII | 2 |
| 2. PRECISION TABLE | 3 |
| 3. INSTALLATION AND LIFTING NOTICE | 5 |
| A. Clean Machine | 6 |
| B. Fastening Equipment for Transit | 6 |
| C. Location of the Machine | 6 |
| 4. INSTALLATION | 7 |
| A. Dimension Maps | 9 |
| 5. LEVELING THE MACHINE | 10 |
| 6. BALANCE OF THE WHEEL | 11 |
| 7. HOW TO DRESS GRINDING WHEEL AND USE DIAMOND DRESSER | 12 |
| 8. INSTALLATION AND DISMANTALING OF THE WHEEL | 14 |
| 9. HYDRAULIC SYSTEM DIAGRAM FOR 618AHII | 15 |
| 10. LUBRICATION SYSTEM AND DIAGRAM | 17 |
| 11. FUNCTIONS OF OPERATION SWITCH | 19 |
| 12. ELECTRIC DIAGRAM | 24 |
| 13. MECHANICAL PART LIST | 38 |
| A. TABLE, SADDLE, AND BASE ASS'Y | 39 |
| B. COLUMN ASS'Y | 42 |
| C. UPPER & LOWER TRANSMISSION ASS'Y | 44 |
| D. SPINDLE ASS'Y | 47 |
| E. CROSSFEED ASS'Y | 49 |
| F. TABLE HAND FEED ASS'Y | 51 |
| G. TABLE, SADDLE, AND BASE ASS'Y (FOR AHII SERIES) | 53 |
| H. COLUMN ASS'Y (FOR AHII SERIES) | 56 |
| I. CROSSFEED ASS'Y (FOR AHII SERIES) | 59 |
| J. TABLE HAND FEED ASS'Y (FOR AHII SERIES) | 62 |
| K. LONGITUDINAL HYDRAULIC CYLINDER ASS'Y (FOR AHII SERIES) | 64 |

DESCRIPTION

PAGE #

L. CROSS SWITCH ASSEMBLY

66

M. VALVE ASSEMBLY


68

N. HYDRAULIC SYSTEM

NA


1. MAIN PART OF THE MACHINE

A. For Supra 618II



- | | |
|--------------------------------------|---------------------------|
| 1. Column | 8. Crossfeed handwheel |
| 2. Wheel guard | 9. Saddle |
| 3. Electrical control panel | 10. Crossfeed travel lock |
| 4. Splash guard | 11. Vertical handwheel |
| 5. Table | 12. Electric cabinet |
| 6. Long. travel stroke adjusting dog | 13. Machine base |
| 7. Long. handwheel | |

B. For Supra 618AHII



- | | |
|--------------------------------------|--------------------------------------|
| 1. Column | 9. Saddle |
| 2. Electrical control panel | 10. Flow control lever |
| 3. Splash guard | 11. Crossfeed travel stroke adjuster |
| 4. Table | 12. Vertical handwheel |
| 5. Long. travel stroke adjusting dog | 13. Electric cabinet |
| 6. Long. handwheel | 14. Machine base |
| 7. Crossfeed handwheel | 15. Coolant system (option) |
| 8. Wheel guard | 16. Hydraulic system |









2. PRECISION TABLE

ACER GROUP ACCURACY LIST

PAGE: 1/2

MODEL:
M/C NO.

UNIT: inch






| INSPECTING ITEM | | I. S. O. | D. I. N. | J. I. S. | C. N. S. | ACER | INSPECTION RECORD |
|--|-----------------------------|---------------------|---------------------|---------------------|---------------------|---------------------|-------------------|
|  1 | Straightness | $\frac{0.0008}{40}$ | $\frac{0.0008}{40}$ | $\frac{0.0008}{40}$ | $\frac{0.0008}{40}$ | $\frac{0.0008}{40}$ | |
| | Longitudinal | | | | | | |
|  2 | of table | $\frac{0.0008}{40}$ | $\frac{0.0008}{40}$ | $\frac{0.0008}{40}$ | $\frac{0.0008}{40}$ | $\frac{0.0008}{40}$ | |
| | Crosswise | | | | | | |
|  2 | Squareness | $\frac{0.0008}{40}$ | $\frac{0.0008}{40}$ | $\frac{0.0008}{40}$ | $\frac{0.0008}{40}$ | $\frac{0.0008}{40}$ | |
| | of table | | | | | | |
|  3 | movement | $\frac{0.0008}{40}$ | $\frac{0.0008}{40}$ | $\frac{0.0008}{40}$ | $\frac{0.0008}{40}$ | $\frac{0.0008}{40}$ | |
| | Long. (in square) | | | | | | |
|  3 | movement | $\frac{0.0006}{18}$ | $\frac{0.0004}{18}$ | $\frac{0.0004}{18}$ | $\frac{0.0004}{18}$ | $\frac{0.0001}{18}$ | |
| | Cross. (in square) | | | | | | |
|  4 | Parallelism of longitudinal | $\frac{0.0004}{6}$ | $\frac{0.0004}{6}$ | $\frac{0.0004}{6}$ | $\frac{0.0004}{6}$ | $\frac{0.00012}{6}$ | |
| | movement | | | | | | |
|  5 | Parallelism of cross | $\frac{0.0012}{12}$ | $\frac{0.0004}{4}$ | $\frac{0.0008}{12}$ | $\frac{0.0008}{12}$ | $\frac{0.0004}{6}$ | |
| | movement | | | | | | |
|  5 | Squareness of longitudinal | $\frac{0.0004}{4}$ | $\frac{0.0004}{4}$ | $\frac{0.0008}{12}$ | $\frac{0.0008}{12}$ | $\frac{0.0004}{6}$ | |
| | movement to cross movement | | | | | | |

ACER GROUP ACCURACY LIST

MODEL:
M/C NO.

UNIT: inch



PAGE: 2/2

| INSPECTING ITEMS | I. S. O. | D. I. N. | J. I. S. | C. N. S. | ACER | INSPECTION RECORD |
|---|---------------------|--------------------|---------------------|---------------------|---------------------|-------------------|
|  6 Run-out of spindle nose | 0.0004 | 0.0002 | 0.0004 | 0.0004 | 0.00008 | |
|  7 Axial slip of spindle | 0.0004 | 0.0002 | 0.0004 | 0.0004 | 0.00008 | |
|  8 Parallelism between spindle centerline to table surface | $\frac{0.001}{12}$ | $\frac{0.0004}{4}$ | $\frac{0.0008}{12}$ | $\frac{0.0008}{12}$ | $\frac{0.0004}{12}$ | |
|  9 Squareness between spindle centerline to table movement | $\frac{0.0006}{12}$ | $\frac{0.0002}{4}$ | $\frac{0.0008}{12}$ | $\frac{0.0008}{12}$ | $\frac{0.0004}{12}$ | |
|  10 Squareness between vertical movement & cross movement & longitudinal movement | $\frac{0.0016}{12}$ | $\frac{0.0004}{4}$ | $\frac{0.0004}{4}$ | $\frac{0.0004}{4}$ | $\frac{0.0002}{4}$ | |

3. INSTALLATION AND LIFTING NOTICE

The machine has been inspected and adjusted before it is shipped out of the factory. The most important thing is to prevent machine from damaging while the machine is in transportation and installation.

Use overhead crane and hook to transport the machine; steel cables, hooks, and four hanging pegs which are located on the two sides of the machine, are used to lift the machine up from the pallet. But you have to pay attention to the balance of the machine, and please put some soft material between steel cables and machine to protect paint from damaging.



Use fork lift to transport the machine as shown on the above drawing.

A. Clean machine

After opening the crate, you will find machine surfaces are processed to prevent from rust. You may see the machine surfaces are coated with thin rust-proof oil. Please wipe off the oil by soft cloth and solvent. Use iron plate or knife will damage the paint surface.

B. Fastening equipment for transit

When moving or packing the machine, table movement is fixed at front Left and rear right side of the table, and saddle movement is fixed from The right and left side between the saddle and the machine base. The Table and saddle are fixed only when the machine is in transit. As soon as the machine is installed in place, you have to loosen the fixtures, and make sure the machine can move smoothly.

C. Location of the machine:

Location choice of the machine will influence the grinding accuracy and Its efficiency. You need to carefully choose its site as if it is a boring machine. Grinder is a very precision machine tool. It needs to be located at a vibration free area, but in fact, many grinders are located among milling machine, drilling machine, shaping machine, and slotting machine. Obviously, we won't be satisfied with the accuracy from these grinders, because the vibration from other machines will transmit to the grinders, and produce chatters on the grinding surface.

Unsteady land cannot locate grinders, since it will cost the machine to loose its correct shape and machine level.

4. INSTALLATION




On shipment, only the table is not assembled, otherwise all other machine parts are assembled. This is done in order to protect the slideways on the table. Therefore after situated the machine base, you must place the table according the following instructions.

For Supra 618II:

1. Circle the steel wire rope four times around the drum (figure 1).
2. Assemble the steel balls and steel ball retainers, and put them on top of the slideways (figure 2).
3. Lift the table carefully and lay it on top of the slideways against the steel balls.
4. Fix the steel wire on the fixing stand under the table (figure 3).
5. The steel wire will gradually loosen and glide on the drum after long usage. In this case, you must adjust the adjusting screw bolt.

For Supra 618 AHII:

1. Assemble the steel balls and steel ball retainers, and put them on top of the slideways (figure 2).
2. Lift the table carefully and lay it on top of the slideways against the steel balls.
3. Make sure cylinder fixed stand situates on top of the piston firmly.
4. Assemble the nuts, washers and rubber pad as shown on figure 4.









Fig 4

A. DIMENSIONS MAP

SUPRA-618AH II




SUPRA-618 II



5. LEVELING THE MACHINE

Generally speaking, the machine doesn't need any of the special foundation, except for very precision grinding. However the machine has to be located on an even and smooth place, where there is no vibration. The levelness of the machine is adjusted by adjusting the three leveling screws. Adjusting the precision level (0.0004/40"), as shown on the drawing, within one graduation.



After adjust the level for the first time, you have to re-adjust the machine once every three months for one year. Thereafter, do it twice every year.

6. BALANCE OF THE WHEEL

Accurate grinding, brightness of work piece, and movement of spindle are contributing factors to the reason of balancing of the wheel. Wheel balancing will also eliminate the wheel's internal stress and prolong the life of the spindle.



First time after grinding wheel is balanced: Lock the grinding wheel (with wheel flange on it) on the spindle tightly, and dress it by diamond dresser until it is evenly dressed. But in order to obtain the real balance of the grinding wheel, you have to take off the wheel and rebalance it again to achieve the balance that it required.

Because different material has to be ground by different grade of grinding wheel, we strongly suggest customer to prepare special grinding wheel with their flanges. So the customer can save the trouble of rebalancing the wheel after the grinding wheel is taken off.

After assembling the wheel and wheel flange (fig1), put the balancing arbor on, and place the assembly on the balancing stand (fig2), then follow the procedure below:

1. Adjust the level of balancing stand (fig3).
2. Let the wheel swings to find out the lower center of gravity and then mark it (v) (fig4).
3. Lock the balancing block (b) on the opposite side of gravity and do not move it any more (fig5).
4. Put two balancing blocks (p) at 120 degree from (b) (fig6).
5. To check wheel's balance, rotate the wheel at about 90 degree each time. If the wheel moves, move the closest block (p) to the opposite rotation of the wheel moving direction. Rotate the wheel around until it is balanced.
6. After wheel is balanced, you must let the wheel running under normal speed for at least five minutes.
7. Since grinding wheel will loose its balance after grinding a long time, you must check and rebalance the wheel occasionally.
8. If you use coolant during grinding, please start the spindle before turning on the coolant. Otherwise the wheel will start out of balance because of water concentrate on one side of the wheel. If the wheel is idle for a long time, the coolant will concentrate at wheel's lowest

center of the gravity point. Therefore when you restart the spindle again, you must run the spindle for at least 10~15 minutes to rebalance the wheel.



7. HOW TO DRESS GRINDING WHEEL AND USE

DIAMOND DRESSER:

- A. When you dress grinding wheel, diamond inevitably wear along the rotating direction, so to eliminate this from happening, the diamond dresser has to be put at a slant angle of 6 degree to dress the wheel (fig 1).
- B. When you are going to dress the grinding wheel, please put the sharp tip of diamond dresser at approximately 0.2" (5mm) to the left bottom of the grinding wheel, and stop the longitudinal movement of working table, then you may move crossfeed in and out slowly to dress the wheel (fig 2).
- C. When you dress the grinding wheel, you must start from the middle, because grinding wheel usually wear more on the end sides than in the middle. If you dress from the two sides to middle, then pressure can build up during grinding (fig 3).




fig 1




fig 2




fig 3

Dressing speed and depth will influence the grinding surface. If you don't ask for best surface or you want bigger grinding capacity, fast or rough dressing is enough. (Dressing depth 0.01~0.03mm each time and coordinate with fast speed across the grinding wheel three or four times.) If you want best surface or last finishing grinding, then the grinding wheel has to treat with careful dressing. (Dressing depth from 0.02mm, 0.01mm to 0.005mm gradually and combine with slow and steady speed across grinding wheel.)

Generally speaking, the useful life of grinding wheel and diamond dresser is longer with fine grinding than rough grinding.

8. INSTALLATION AND DISMANTLING OF THE GRINDING WHEEL


WHEEL

Installation:


- A. Choose the side with bigger conical surface for grinding wheel toward inside, and carefully put it on the spindle.
- B. Firmly tighten the spindle nut counterclockwise (by movable wrench or open wrench).

Dismantling:


- A. Loosen the spindle nut clockwise with wrench.
- B. Firmly hold the grinding wheel by one hand, and screw in the wheel flange extractor until the grinding wheel assembly breaks away from the spindle. Then you can take down the grinding wheel.



9. HYDRAULIC SYSTEM DIAGRAM FOR 618AH II



HYDRAULIC CIRCUIT DIAGRAM



***Normal hydraulic pressure on the gauge is between 10~15 kg/cm².


| | | |
|-----|-------------------------|----------------|
| 1 | Cylinder | |
| 2 | Volume control valve | |
| 3 | Pressure reducing valve | |
| 4 | Hydraulic pump | 16CC/REV |
| 5 | Hydraulic motor | 1HP/6P |
| 6 | Manifold | |
| 6.1 | Directional valve | |
| 6.2 | Solenoid control valve | |
| 7 | Pressure gauge | |
| 8 | Strainer | |
| A | High pressure hose | 3/8"*1100mm(L) |
| B | High pressure hose | 3/8"*1400mm(L) |
| P | High pressure hose | 3/8"*1100mm(L) |
| P1 | High pressure hose | 3/8"*1100mm(L) |
| T | High pressure hose | 3/8"*1100mm(L) |

10. LUBRICATION SYSTEM AND DIAGRAM

Lubrication system affects the accuracy and life-long of the machine. Our machine is equipped with automatic lubrication system for easier operator's maintenance. In order to keep the machine in the best condition, the user has to pay attention to the following:

- A. Keep the lubrication oil more than 1/3 at lubrication tank at any time.
- B. Check the slideways' lubrication condition. When they are dry, stop the machine immediately. Do not operate the machine until the lubrication problem is corrected.
- C. Please use the indicated brand and grade of the lubrication oil in order to obtain the best lubrication condition.
 - **Mobile Vactra #2 waylube oil, Chevron waylube 68X.
 - **Oil pumps every 30 minutes at 6cc each time. To change pumping time, turn the variable resistor to desired time position.
- D. When the waylube oil is under low level, the buzzer will sound. Please add more way oil immediately.

AUTO LUBRICANT SYSTEM AND DIAGRAM




| ITEM NO. | PARTS NO. | DESCRIPTION |
|----------|------------|-------------------------------------|
| A. | YESC(110V) | Auto Lubrication Pump |
| B. | 9026 | 7 Way Distributor |
| C. | 9004 | 3 Way Distributor |
| 1. | 9027 | To 7 Way Distributor |
| 2. | 9028 | To Left Crossfeed Slideway |
| 3. | 9029 | To Crossfeed Leadscrew Set |
| 4. | 9030 | To Elevation Leadscrew Set |
| 5. | 9031 | To Light Crossfeed Slideway |
| 6. | 9032 | To Elevation Leadscrew Set |
| 7. | 9033 | To Elevation Leadscrew Set |
| 8. | 9002 | 4mm Aluminum Pipe Tubing NO.1,4,6,7 |
| 9. | 9025 | 4mm PE (Pastic) Tubing NO.2,3,5 |

11. FUNCTIONS OF OPERATION SWITCH

Supra 618II Control Panel and Its Parts List


Description table in motors:

1. 1MTR – Spindle (Wheel head) motor: 2.2KW, 3-phase, AC motor.
2. 3MTR – Coolant pump motor: 0.2KW , 3-phase, AC motor.
3. 3MTR – Vacuum/Dust - exhaust motor: 0.4KW , 3-phase, AC motor.
4. 8MTR – Lubrication motor: 10W , 1-phase, 110VAC motor.



Control station:

| No. | Description | Parts NO. | Type reference | Supplier |
|-----|-----------------------|---------------|------------------|----------|
| 1. | Control station panel | GPE-618-E-001 | Acer-618 panel | ACER |
| 2. | Power On indicator | GPE-618-E-002 | TPN-127R | Tend |
| 3. | Spindle On | GPE-618-E-003 | MK/ABLFC-22G/24V | Mark |
| 4. | Coolant/Dust. On | GPE-618-E-004 | MK/ABLFC-22G/24V | Mark |
| 5. | Stop | GPE-618-E-005 | MK/ABFP-22R | Mark |
| 6. | Emergency Stop | GPE-618-E-006 | AE-22 (Lock) | Mark |



DESCRIPTION OF CONTROL PANEL FOR 618AHII

| Item # | Description | Parts Number | Name on Circuit |
|--------|-----------------------------|---------------|-----------------|
| 1. | Control Panel Plate | GPE618AH-001 | |
| 2. | Emergency Push Button | GPE618AH-002 | PB1 |
| 3. | Power on Button with Light | GPE618AH-003 | PB2 |
| 4. | Spindle on Button | GPE618AH-004 | PB3 |
| 5. | Hydraulic on Button | GPE618AH-004 | PB5 |
| 6. | Coolant/Dust on Button | GPE618AH-004 | PB7 |
| 7. | Spindle off Button | GPE618AH-007 | PB4 |
| 8. | Hydraulic off Button | GPE618AH-007 | PB6 |
| 9. | Coolant/Dust off Button | GPE618AH-007 | PB8 |
| 10. | Crossfeed Inward | GPE618AH-004 | PB11 |
| 11. | Crossfeed Outward | GPE618AH-004 | PB12 |
| 12. | Rapid/Step Selector | GPE618AH-012 | SS1 |
| 13. | Step Adjustment VR | GPE618AH-013 | POT1 |
| 13-1. | Step Adjustment Knob | GPE618AH-013K | |
| 14. | LED Display(Opt) | GPE618AH-014 | DVM1 |
| 15. | Demagnetizer Timer(Opt) | GPE618AH-015 | DEMAG. |
| 16. | Magnetizer VR(Opt) | GPE618AH-015 | MAG. |
| 17. | Demag. Indicator Light(Opt) | GPE618AH-017 | |
| 18. | Mag. Indicator Light(Opt) | GPE618AH-018 | |
| 19. | Mag./Demag. Selector(Opt) | GPE618AH-019 | |
| 20. | Power up Button (Opt.) | GPE618AH-020 | |
| 21. | Power down Button(Opt.) | GPE618AH-020 | |
| 22. | Chuck Controller (Opt.) | GPE-CMR5G | |


ELECTRIC PARTS OF CONTROL PANEL FOR 618AHIII

| Item # | Description | Type Reference | Supplier |
|--------|-----------------------------|------------------|------------|
| 1. | Control Panel Plate | ACER 618AH Panel | ACER |
| 2. | Emergency Push Button | MK/AE-22 (Lock) | Mark |
| 3. | Power on Button with Light | MK/ABLFC-22W/24V | Mark |
| 4. | Spindle on Button | MK/ABLFC-22G/24V | Mark |
| 5. | Hydraulic on Button | MK/ABLFC-22G/24V | Mark |
| 6. | Coolant/Dust on Button | MK/ABLFC-22G/24V | Mark |
| 7. | Spindle off Button | MK/ABFP-22R | Mark |
| 8. | Hydraulic off Button | MK/ABFP-22R | Mark |
| 9. | Coolant/Dust off Button | MK/ABFP-22R | Mark |
| 10. | Crossfeed Inward | MK/ABLFC-22G/24V | Mark |
| 11. | Crossfeed Outward | MK/ABLFC-22G/24V | Mark |
| 12. | Rapid/Step Selector | MK/AC-22B | Mark |
| 13. | Step Adjustment VR | RV24YN 20S, B502 | COSMOS |
| 13-1 | Step Adjustment Knob | #596B | Wafer |
| 14. | LED Display(Opt) | DVM1 Card | Maytronics |
| 15. | Demagnetizer Timer(Opt) | 503B, d24 | |
| 16. | Magnetizer VR(Opt) | 503B, d24 | |
| 17. | Demag. Indicator Light(Opt) | Red, d8 | |
| 18. | Mag. Indicator Light(Opt) | Green, d8 | |
| 19. | Mag./Demag. Selector(Opt) | 3B, d7 | Alpus |
| 20. | Power up Button(Opt.) | MK/ABLFC-22B/24V | Mark |
| 21. | Power down Button(Opt.) | MK/ABLFC-22B/24V | Mark |
| 22. | Chuck Controller(Opt) | CMR-5G | Maytronics |

OPERATION PROCEDURE FOR 618AHII


1. To turn on the spindle, push PB3 to turn on the spindle.
2. To turn off the spindle, push PB4 to turn off the spindle.
3. To turn on the hydraulic system, push PB5 to turn off the hydraulic system.
4. To turn off the hydraulic system, push PB6 to turn off the hydraulic system.
5. To turn on the coolant/dust system, push PB7 to turn on the coolant/dust system.
6. To turn off the coolant/dust system, push PB8 to turn off the coolant/dust system.
7. To operate rapid crossfeed, turn SS1 to hand position.
8. To operate step crossfeed, turn SS1 to auto-cycle position. Then push either PB11 or PB12 to activate the automatic crossfeed cycle. During the automatic cycle, when the crossfeed is traveling inward, push PB12 will reverse its direction immediately. Converse will happen when execute.
9. To adjust the step feed amount, turn POT1 to desire position for crossfeed increment.
10. To adjust demagnetizer time, adjust DEMAG. to desired time.
11. To adjust magnetizer power, adjust MAG. VR to desired position.
12. To select demag. or mag., turn item 19 to desired position to activate its function.
13. To rapid up the spindle housing, push item 20. (option not available on 618AHII)
14. To rapid down the spindle housing, push item 21. (option not available on 618AHII)
15. To turn off the power to control panel, push in PB1. It will shut off all functions on the control panel. To turn on the power again, release PB1 by turning it on the knob.

12. ELECTRIC DIAGRAM



ACER - 618

Main control power & motors circuit diagram



ACER - 618


Main control panel layout diagram

ELECTRIC CABINET FOR 618II

| No. | Description | Type reference | Supplier |
|-----|------------------------------------|-------------------------------------|----------|
| 1. | Main switch | OT16E3 | ABB |
| 2. | Main control power transformer | 1T, 300VA | Taku |
| 3. | DIN Rail mounting track | For components mounting, INTBR-N | Mark |
| 4. | Manual spindle motor starter | 1M, RAB-09T10A C1 | Riken |
| 5. | Manual coolant/dust. motor starter | 3M, RAB-09T10A C1 | Riken |
| 6. | Spindle motor overload | 1OL, BTH-18T2H8, 5.4~8A | Riken |
| 7. | Coolant/dust. motor overload | 3OL, BTH-18T2H2.8, 1. 8~2.8A | Riken |
| 8. | Auxiliary contact | RA1-T11, 1a1b | Riken |
| 9. | Main terminal blocks | 1TB, TBC-10 | Tend |
| 10. | End stops of terminal blocks | For 1TB, TBC-F | Tend |
| 11. | Fuse holder | 1FU, 2FU and 3FU, FB-103R | Mack |
| 12. | Fuse holder | 4FU, FB-101R | Mark |
| 13. | Fuse cover | For 1FU, 2FU, 3FU &4FU, FB-10N | Mack |
| 14. | Terminal blocks | 1TB, TBC-10 | Tend |
| 15. | Terminal blocks stop | TBC-F | Tend |
| 16. | Terminal blocks | 2TB, TB25-4 | Tend |
| 17. | Coolant/dust. connector | J2, LLPM508-25-4 | Lan Ling |
| 18. | Fuse holder (Option) | For 1MFU | df PM F |


Compatible table of electrical parts

| No. | Description | Type reference | Supplier |
|-----|-----------------------------|-----------------|----------|
| 1. | Riken RAB-09TXXA C1 (24VAC) | 100-A09K series | AB |
| | | LC1-D09B series | TE |
| | | CN-11 series | TaiAn |
| 2. | Riken BTH-18T2HXX | 193-A1 series | AB |
| | | LR1-D093 series | TE |
| | | RH-10E series | TaiAN |
| 3. | Mark MK/AE-22 series | LE series | AB |
| | | ZB2 series | TE |
| 4. | Mark MK/ABXXX-22 series | LF series | AB |
| | | ZB2 series | TE |




ACER - 618 AH

Main control power & motors circuit diagram



ACER - 618 AH
Main power transformer circuit diagram



ACER - 618 AH
Main control circuit diagram

D

D

C


C

B

B

A

A




- 1LS: Rightward stroke
- 2LS: Leftward stroke
- 3LS: Outward stroke
- 4LS: Inward stroke
- 5LS: Throttle emplacement
- 7LS: Inward / outward limit
- 4M: Inward starter
- 5M: Outward starter
- PB11: Inward direction
- PB12: Outward direction
- POT1: Step increment adjustment
- SS1: Rapid / step selector
- LD1: Indicator of rightward solenoid
- LD2: Indicator of leftward solenoid
- LD3: Indicator of inward motion
- LD4: Indicator of outward motion
- LD5: Indicator of trigger signal
- VR1: Adjustment of maximum travel
- VR2: Adjustment of delay trigger

ACER - 618 AH

2A controller connection diagram

Electric chuck controller
CMR-5G




ACER-618AH Electric parts listing

Description table in motors:

1. 1MTR – Spindle (Wheel head) motor: 2.2KW, 3-phase, AC motor.
2. 2MTR – Hydraulic pump motor: 0.75KW, 3-phase, AC motor.
3. 3MTR – Coolant pump motor: 0.2KW, 3-phase, AC motor.
4. 3MTR – Dust - exhaust motor: 0.4KW, 3-phase, AC motor.
5. 4MTR – Cross feed motor: 40W, 3-phase, 220VAC motor.
6. 5MTR (Option) – Elevator motor: 40W, 3-phase, 220VAC motor
7. 8MTR – Lubrication motor: 10W, 1-phase, 110VAC motor.

Peripheral electrical devices:

| No. | Description | Type reference | Supplier |
|-----|-------------------------------------|--|----------|
| 1. | Terminal blocks of saddle enclosure | For cross feed motor, 230WP | Teilbar |
| 2. | Hydraulic system connector | J1, LLPM509-30-7 | Lan Ling |
| 3. | Coolant/Dust. connector | J2, LLPM508-25-4 | Lan Ling |
| 4. | 110VAC receptacle | For working lamp or linear scale only. 110VAmx. LK 3021F | LKEW |
| 5. | Right motion detector | Proximity switch, TL-B5NE1KFPS | |
| 6. | Left motion detector | Proximity switch, TL-B5NE1KFPS | |
| 7. | Inward motion stroke | Limit switch, MJ2-1308 | Moujen |
| 8. | Outward motion stroke | Limit switch, MJ2-1308 | Moujen |
| 9. | Outward/Inward motion limit | Limit switch, ME - 8104 | Moujen |
| 10. | Upward motion limit (Option) | Limit switch, ME - 1704 | Moujen |



ACER - 618 AH (Option)

Main control panel layout diagram

ELECTRIC CABINET FOR 618AHII

| No. | Description | Type reference | Supplier |
|-----|---|--------------------------------------|------------|
| 1. | Main switch (Option) | OT16E3 | ABB |
| 2. | Main control power transformer | 1T, 580VA | Jeau Yi |
| 3. | 2-Axes motion controller | Model: 2A Controller | Maytronics |
| 4. | DIN Rail mounting track | For components mounting, INTBR-N | Mark |
| 5. | Manual spindle motor starter | 1M, RAB-09T10A C1 | Riken |
| 6. | Manual hydraulic pump motor starter | 2M, RAB-09T10A C1 | Riken |
| 7. | Manual coolant/dust. motor starter | 3M, RAB-09T10A C1 | Riken |
| 8. | Cross feed direction controller | 4M & 5M, RAB-09T01A C1 | Riken |
| 9. | Mechanical interlock of cross feed direction controller | For 4M & 5M, RK-351 | Riken |
| 10. | Up/down direction controller (Option) | 6M & 7M, RAB-09T01A C1 | Riken |
| 11. | Mechanical interlock of cross feed direction controller (Option) | For 6M & 7M, RK-351 | Riken |
| 12. | Spindle motor overload | 1OL, BTH-18T2H8, 5.4~8A | Riken |
| 13. | Hydraulic pump motor overload | 1OL, BTH-18T2H4.3, 2.9~4.3A | Riken |
| 14. | Coolant/dust. motor overload | 3OL, BTH-18T2H2.8, 1.8~2.8A | Riken |
| 15. | Cross feed motor overload | 4OL, BTH-18T2H2.8, 0.3~0.4A | Riken |
| 16. | Elevator motor overload (Option) | 5OL, BTH-18T2H2.8, 0.3~0.4A | Riken |
| 17. | Main terminal blocks | 1TB & 2TB, TBC-10 | Tend |
| 18. | End stops of terminal blocks | For 1TB, TBC-F | Tend |
| 19. | Fuse holder (Option) | For 1MFU PM F (10X38) Tripolar | df PM F |
| 20. | Fuse holder | 1FU, 2FU and 3FU, FB-103R | Mack |
| 21. | Fuse holder | 4FU, FB-101R | Mark |
| 22. | Fuse cover | For 1FU, 2FU, 3FU and 4FU, FB-10N | Mark |
| 23. | Power on relay | LY2Z 24VAC | OMRON |

Compatible table of electrical parts


| No. | Description | Type reference | Supplier |
|-----|-----------------------------|-----------------|----------|
| 1. | Riken RAB-09TXXA C1 (24VAC) | 100-A09K series | AB |
| | | LC1-D09B series | TE |
| | | CN-11 series | TaiAn |
| 2. | Riken BTH-18T2HXX | 193-A1 series | AB |
| | | LR1-D093 series | TE |
| | | RH-10E series | TaiAN |
| 3. | Mark MK/AE-22 series | LE series | AB |
| | | ZB2 series | TE |
| 4. | Mark MK/ABXXX-22 series | LF series | AB |
| | | ZB2 series | TE |
| 5. | Mark MK/AC-22 series | SM22 series | AB |
| | | XB2 series | TE |
| 6. | KFPS TL-B5NE1 | TL-N5ME1 | OMRON |
| 7. | Moujen MJ2 - 1308 | D4MC-2020 | OMRON |
| 8. | Moujen ME - 8104 | D4D-1120N | OMRON |
| 9. | Moujen ME - 1704 | SHL-Q2255 | OMRON |

Mechanical Parts List

To order parts, please have the following information ready:

- 1. Year of production**
- 2. Model and serial number**
- 3. Item number and description**
- 4. Quantity**

TABLE, SADDLE, BASE ASS'Y



TABLE, SADDLE AND BASE ASS'Y

(618-01)


| Index No. | Parts No. | Parts Name | Q'ty | Spec. |
|-----------|------------|-----------------------|------|----------|
| 1 | 618-01-001 | Splash Guard (Frame) | 1 | |
| 2 | 618-01-002 | Splash Guard (Plate) | 3 | |
| 3 | | Socket Head Cap Screw | 4 | M6*10L |
| 4 | 618-01-003 | Table | 1 | |
| 5 | 618-01-004 | Steel Ball Way | 1 | |
| 6 | | Socket Head Cap Screw | 12 | M6*25L |
| 7 | 618-01-005 | Steel Ball Way | 1 | |
| 8 | 618-01-006 | Ball Retainer | 9 | |
| 9 | 618-01-017 | Steel Ball | 43 | |
| 10 | 618-01-007 | Steel Ball Way | 2 | |
| 11 | | Hex. Nut | 2 | |
| 12 | 618-01-020 | Travel Stopper | 2 | |
| 13 | | Snap Ring | 2 | $\phi 6$ |
| 14 | | Hex. Nut | 2 | M8 |
| 15 | | Socket Head Cap Screw | 2 | M8*30L |
| 16 | 618-01-018 | Spring | 2 | |
| 17 | 618-01-019 | Stopper Screw | 2 | |
| 18 | 618-01-009 | Setting Plate | 4 | |
| 19 | | Socket Head Cap Screw | 8 | M5*10L |
| 20 | 618-01-021 | Black Bakelite Ball | 1 | |
| 21 | | Hex Nut | 1 | M6 |
| 22 | | Set Screw | 1 | M6*20L |
| 23 | 618-01-022 | Table Bracket Base | 1 | |
| 24 | 618-01-023 | Rubber Spacer | 1 | |
| 25 | | Set Screw | 1 | M8*20L |
| 26 | 618-01-024 | Table Bracket Base | 1 | |

TABLE, SADDLE AND BASE ASS'Y

(618-01)

| Index No. | Parts No. | Parts Name | Q'ty | Spec. |
|-----------|------------|--------------------------|------|--------|
| 27 | 618-01-025 | Round End Screw | 1 | |
| 28 | | Socket Head Cap Screw | 2 | M6*20L |
| 29 | 618-01-010 | Saddle | 1 | |
| 30 | 618-01-026 | Coolant Hose Connector | 1 | |
| 31 | 618-01-011 | Handle (ADJUSTABLE) | 1 | |
| 32 | 618-01-027 | Crossfeed Stopping Plate | 1 | |
| 33 | 618-01-028 | Stopping Plate Spacer | 1 | |
| 34 | | Socket Head Cap Screw | 3 | M5*16L |
| 35 | 618-01-029 | Lube Pump Cover Plate | 1 | |
| 36 | | Socket Head Cap Screw | 2 | M5*8L |
| 37 | 618-01-030 | Crossfeed Locking Base | 1 | |
| 38 | 618-01-011 | Handle (Adjustable) | 1 | |
| 39 | | Socket Head Cap Screw | 2 | M5*35L |
| 40 | 618-01-013 | Base | 1 | |
| 41 | 618-01-014 | Leveling Screw | 3 | |
| 42 | 618-01-015 | Leveling Block | 3 | M8*16 |
| 43 | | Socket Head Cap Screw | 4 | |
| 44 | 618-01-031 | Electrical Cabinet | 1 | M6*20L |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

COLUMN ASS'Y




COLUMN ASS'Y

(618-02)

| Index No. | Parts No. | Parts Name | Q'ty | Spec. |
|-----------|------------|------------------------|------|----------|
| 1 | 618-02-001 | Wheel Guard | 1 | |
| 2 | | E-Snap Ring | 1 | $\phi 8$ |
| 3 | 618-02-002 | Lock Screw | 1 | |
| 4 | | Cross Head Screw | 6 | M5*10L |
| 5 | 618-02-003 | Front Guard | 1 | |
| 6 | 618-02-004 | Front Guard | 1 | |
| 7 | 618-02-005 | Front Guard | 1 | |
| 8 | 618-02-006 | Front Guard | 1 | |
| 9 | 618-02-007 | Front Guard | 1 | |
| 10 | 618-02-008 | Front Guard | 1 | |
| 11 | 618-02-009 | Head A Housing | 1 | |
| 12 | 618-02-010 | Copper Collar | 2 | |
| 13 | | Socket Head Cap Screw | 2 | M10*40L |
| 14 | 618-02-011 | Plastic Cover | 2 | |
| 15 | 618-02-012 | Shield Dust Guide Rail | 2 | |
| 16 | 618-02-013 | Column | 1 | |
| 17 | | Hexagonal Head Screw | 3 | 3/4"*65L |
| 18 | 618-02-014 | Plastic Cover | 12 | |
| 19 | | Socket Head Cap Screw | 12 | M10*16L |
| 20 | 618-02-015 | Head B Housing | 1 | |
| 21 | 618-02-016 | Column Rear Cover | 1 | |
| 22 | | Cross Head Screw | 6 | M5*8L |
| 23 | | Socket Head Cap Screw | | M10*30L |
| 24 | | Socket Head Cap Screw | | M10*40L |
| | | | | |
| | | | | |

UPPER & LOWER TRANSMISSION ASS'Y




UPPER & LOWER TRANSMISSION ASS'Y

(618-03)

| Index No. | Parts No. | Parts Name | Q'ty | Spec. |
|-----------|------------|---------------------------------|------|--------------|
| 1 | 618-03-001 | Grip | 1 | |
| 2 | 618-03-002 | Handwheel | 1 | |
| 2.1 | 618-03-016 | Spacer | 1 | |
| 3 | 618-03-003 | Cap Nut | 1 | |
| 4 | 618-03-004 | Graduation Dial | 1 | |
| 5 | 618-03-005 | Graduation Dial Holder | 1 | |
| 6 | 618-03-006 | Hexagonal Nut | 2 | |
| 7 | | Snap Ring | 1 | R52 |
| 8 | | Ball Bearing | 1 | 1205 |
| 9 | | Washer | 2 | |
| 10 | 618-03-016 | Spring | 1 | |
| 11 | 618-03-017 | Snap Ring | 1 | |
| 12 | | Key | 1 | 5*5*20L |
| 13 | 618-03-007 | Bracket | 1 | |
| 14 | | Socket Head Cap Screw | 3 | M8*20L |
| 15 | 618-03-008 | Transmission Shaft | 1 | |
| 16 | | Ball Bearing | 1 | 6204 |
| 17 | 618-03-009 | Bevel Pinion | 1 | |
| 18 | | Spring Pin | 1 | ϕ 6*30L |
| 19 | 618-03-010 | Gear Seat | 1 | |
| 20 | | Socket Head Cap Screw | 3 | M12*60L |
| 21 | | Ball Bearing | 1 | 51108 |
| 22 | 618-03-011 | Upper & Lower Lead Screw Socket | 1 | |
| 23 | 618-03-012 | Upper & Lower Lead Screw | 1 | |
| 24 | | Socket Head Cap Screw | 2 | M8*16L |
| 25 | 618-3-013 | Connect Bracket | 1 | |

SPINDLE ASS'Y




SPINDLE ASS'Y

(618-04)

| Index No. | Parts No. | Parts Name | Q'ty | Spec. |
|-----------|------------|-------------------|------|----------|
| 1 | 618-04-013 | Spindle Motor | 1 | |
| 2 | | Key | 2 | 8*30L |
| 3 | | Set Screw | 2 | M8*10 |
| 4 | 618-04-011 | Coupling | 2 | |
| 5 | 618-04-012 | Rubber Coupling | 1 | |
| 6 | 618-04-014 | Spindle Assembly | 1 | |
| 7 | | Set Screw | 3 | M4*5 |
| 8 | 618-04-015 | Balance Block | 3 | |
| 9 | 618-04-016 | Steel Ball | 3 | $\phi 3$ |
| 10 | 618-04-017 | Wheel Hub | 1 | |
| 11 | 618-04-018 | Washer | 1 | |
| 12 | 618-04-019 | Wheel Setting Nut | 1 | |
| 13 | 618-04-020 | Spindle Nut | 1 | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

CROSS FEED ASS'Y



CROSS FEED ASS'Y

(618-05)

| Index No. | Parts No. | Parts Name | Q'ty | Spec. |
|-----------|------------|-----------------------------|------|--------------|
| 1 | 618-05-001 | Grip | 1 | |
| 2 | 618-05-002 | Cap Nut | | |
| 3 | | Washer | 1 | ϕ 10 |
| 4 | 618-05-003 | Handwheel | 1 | |
| 5 | 618-05-004 | Graduation Dial | 1 | |
| 6 | 618-05-005 | Hexagonal Nut | 1 | |
| 7 | | Lock Washer | 1 | |
| 8 | 618-05-006 | Bearing Retainer | 1 | |
| 9 | | Bearing | 1 | 5204ZZ |
| 10 | 618-05-007 | Graduation Dial Holder | 1 | |
| 11 | | Key | 1 | 5*5*30L |
| 12 | 618-05-008 | Crossfeed Leadscrew | 1 | |
| 13 | 618-05-009 | Leadscrew Backlash Adjuster | 1 | |
| 14 | | Socket Head Cap Screw | 2 | M6*16L |
| 15 | | Socket Head Cap Screw | 2 | M6*20L |
| 16 | 618-05-010 | Leadscrew Nut | 1 | |
| 17 | | Key | 1 | 5*5*20L |
| 18 | 618-05-011 | Leadscrew Nut Base | 1 | |
| 19 | | Socket Head Cap Screw | 4 | M8*40L |
| 20 | 618-05-012 | Round Pin | 1 | ϕ 5*10L |
| 21 | 618-05-013 | Socket Head Cap Screw | 1 | |
| | | | 1 | |
| | | | | |
| | | | | |
| | | | | |

TABLE HAND FEED ASS'Y





TABLE HAND FEED ASS'Y

(618-06)

| Index No. | Parts No. | Parts Name | Q'ty | Spec. |
|-----------|------------|---------------------------|------|--------|
| 1 | 618-06-001 | Grip | 1 | |
| 2 | 618-06-002 | Handwheel | 1 | |
| 3 | | Cap Nut | 1 | M12 |
| 4 | | Washer | 1 | ϕ 12 |
| 5 | | Spring | 1 | |
| 6 | 618-06-003 | Gear Clutch | 1 | |
| 7 | 618-06-004 | Gear Clutch | 1 | |
| 8 | | Bearing | 2 | 6803ZZ |
| 9 | 618-06-005 | Shaft Sleeve | 1 | |
| 10 | 618-06-006 | Shaft | 1 | |
| 11 | | Key | 1 | 5x 20L |
| 12 | 618-03-007 | Steel Wire | 1 | |
| 13 | | Washer | 4 | ϕ 8 |
| 14 | | Nut | 4 | M8 |
| 15 | 618-03-008 | Steel Wire Fixed Seat (L) | 1 | |
| 16 | 618-03-008 | Steel Wire Fixed Seat (R) | 1 | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

TABLE, SADDLE, BASE ASS'Y (FOR AH SERIES)



TABLE, SADDLE AND BASE ASS'Y (FOR AH SERIES

(618-01)


| Index No. | Parts No. | Parts Name | Q'ty | Spec. |
|-----------|------------|---------------------------|------|--------------|
| 1 | 618-01-001 | Splash Guard (Frame) | 1 | |
| 2 | 618-01-002 | Splash Guard (Plate) | 3 | |
| 3 | | Socket Head Cap Screw | 4 | M6*10L |
| 4 | 618-01-003 | Table | 1 | |
| 5 | 618-01-032 | Rack Gear Seat | 1 | |
| 6 | | Socket Head Cap Screw | 6 | M6*20L |
| 7 | | Socket Head Cap Screw | 6 | M5*10L |
| 8 | 618-01-033 | Rack Gear | 1 | |
| 9 | 618-01-034 | Adjusting Block | 2 | |
| 10 | | Pin | 2 | ϕ 6*30L |
| 11 | | Head Screw | 2 | M8*25L |
| 12 | | Nut | 2 | M8 |
| 13 | | Headless Screw | 2 | M8*8L |
| 14 | 618-01-035 | Switch Cover | 1 | |
| 15 | | Socket Head Cap Screw | 3 | M5*10L |
| 16 | 618-01-010 | Saddle | 1 | |
| 17 | | Socket Head Cap Screw | 3 | M5*8L |
| 18 | 618-01-036 | Adjust Limit Switch Cover | 1 | |
| 19 | 618-01-037 | Rear Limit Block | 1 | |
| 20 | 618-01-038 | Front Limit Block | 1 | |
| 21 | | Socket Head Cap Screw | 2 | M6*20L |
| 22 | | Socket Head Cap Screw | 2 | M5*8L |
| 23 | 618-01-039 | Limit Switch Cover | 1 | |
| 24 | 618-01-040 | Throttling Valve Seat | 1 | |
| 25 | | Socket Head Cap Screw | 2 | M8*16L |
| 26 | 618-01-041 | Limit Switch | 1 | |
| 27 | | Cross Head Cap Screw | 2 | M4*30L |
| 28 | | Socket Head Cap Screw | 4 | M10*50L |

TABLE, SADDLE AND BASE ASS'Y (FOR AH SERIES

(618-01)

| Index No. | Parts No. | Parts Name | Q'ty | Spec. |
|-----------|------------|-----------------------|------|-----------|
| 29 | 618-01-029 | Lube Pump Cover Plate | 1 | |
| 30 | | Socket Head Cap Screw | 4 | M6*20L |
| 31 | | Machine Base | 1 | |
| 32 | 618-01-014 | Leveling Screw | 3 | W7/8"*96L |
| 33 | 618-01-015 | Leveling Block | 3 | |
| 34 | 618-01-042 | Electrical Box | 1 | |
| 35 | | Socket Head Cap Screw | 2 | M6*20L |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

COLUMN ASS'Y (FOR AH SERIES)



COLUMN ASS'Y (FOR AH SERIES)

(618-02)

| Index No. | Parts No. | Parts Name | Q'ty | Spec. |
|-----------|------------|------------------------|------|------------|
| 1 | 618-02-001 | Wheel Guard | 1 | |
| 2 | | E-Snap Ring | 1 | |
| 3 | 618-02-002 | Lock Screw | 1 | |
| 4 | | Cross Head Screw | 6 | M5*10L |
| 5 | 618-02-003 | Front Guard | 1 | |
| 6 | 618-02-004 | Front Guard | 1 | |
| 7 | 618-02-005 | Front Guard | 1 | |
| 8 | 618-02-006 | Front Guard | 1 | |
| 9 | 618-02-007 | Front Guard | 1 | |
| 10 | 618-02-008 | Front Guard | 1 | |
| 11 | 618-02-009 | Head A HOUSING | 1 | |
| 12 | 618-02-010 | Copper Collar | 2 | |
| 13 | | Socket Head Cap Screw | 2 | M10*40L |
| 14 | 618-02-011 | Plastic Cover | 2 | |
| 15 | 618-02-012 | Shield Dust Guide Rail | 2 | |
| 16 | 618-02-013 | Column | 1 | |
| 17 | | Hexagonal Head Screw | 4 | 3/4" * 65L |
| 18 | 618-02-014 | Plastic Cover | 12 | |
| 19 | | Socket Head Cap Screw | 12 | M10*16L |
| 20 | 618-02-015 | Head B HOUSING | 1 | |
| 21 | 618-02-016 | Column Rear Cover | 1 | |
| 22 | | Cross Head Screw | 6 | M5*8L |
| 23 | | Socket Head Cap Screw | 12 | M10*30L |
| 24 | | Socket Head Cap Screw | 12 | M10*40L |
| 25 | | Socket Head Cap Screw | 4 | M6*20L |
| 26 | 618-02-017 | Control Arm | 1 | |

UPPER & LOWER TRANSMISSION ASS'Y

(618-03)


| Index No. | Parts No. | Parts Name | Q'ty | Spec. |
|-----------|------------|--------------|------|--------------|
| 26 | | Spring Pin | 1 | ϕ 6*30L |
| 27 | | Key | 1 | 7*5*25 |
| 28 | | Ball Bearing | 1 | 6011Z |
| 29 | 618-03-014 | Bevel Gear | 1 | |
| 30 | 618-03-015 | Lock Nut | 1 | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

COLUMN ASS'Y (FOR AH SERIES)

(618-02)

| Index No. | Parts No. | Parts Name | Q'ty | Spec. |
|-----------|------------|-----------------------|------|--------|
| 27 | 618-02-018 | Control Cylinder Base | 1 | |
| 28 | 618-02-019 | Cylinder Fixing Plate | 1 | |
| 29 | | Socket Head Cap Screw | 4 | M5*10 |
| 30 | | O-Ring | 1 | P44 |
| 31 | | Socket Head Cap Screw | 3 | M5*10L |
| 32 | 618-02-020 | Control Fixing Plate | 1 | |
| 33 | 618-02-021 | Lock Nut | 1 | |
| 34 | 618-02-022 | Control Box | 1 | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

CROSS FEED ASS'Y (FOR AH SERIES)



CROSS FEED ASS'Y (FOR AH SERIES)

(618-05)

| Index No. | Parts No. | Parts Name | Q'ty | Spec. |
|-----------|------------|-----------------------------|------|--------------|
| 1 | 618-05-001 | Grip | 1 | |
| 2 | 618-05-002 | Cap Nut | 1 | |
| 3 | | Washer | 1 | ϕ 10 |
| 4 | 618-05-003 | Handwheel | 1 | |
| 5 | 618-05-004 | Graduation Dial | 1 | |
| 6 | 618-05-005 | Hexagonal Nut | 1 | |
| 7 | | Lock Washer | 1 | ϕ 20 |
| 8 | 618-05-006 | Bearing Retainer | 1 | |
| 9 | | Bearing | 1 | 5204ZZ |
| 10 | 618-05-007 | Graduation Dial Holder | 1 | |
| 11 | | Key | 1 | 5*5*30L |
| 12 | 618-05-008 | Crossfeed Leadscrew | 1 | |
| 13 | 618-05-009 | Leadscrew Backlash Adjuster | 1 | |
| 14 | | Socket Head Cap Screw | 2 | M6*16L |
| 15 | | Socket Head Cap Screw | 2 | M6*20L |
| 16 | 618-05-010 | Leadscrew Nut | 1 | |
| 17 | | Key | 1 | 5*5*20L |
| 18 | 618-05-011 | Leadscrew Nut Base | 1 | |
| 19 | | Socket Head Cap Screw | 4 | M8*40L |
| 20 | 618-05-012 | Round Pin | 1 | ϕ 5*10L |
| 21 | 618-05-013 | Socket Head Cap Screw | 1 | |
| 22 | 618-05-014 | LEADSCREW Pulley | 1 | |
| 23 | | Set Screw | 1 | M6*8L |
| 24 | 618-05-015 | Timing Belt | 1 | 160XL |
| 25 | 618-05-016 | Motor Pulley | 1 | |
| 26 | | Set Screw | 1 | M5*5L |
| 27 | | Socket Head Cap Screw | 4 | M6*16L |
| 28 | 618-05-017 | Motor Fixing Plate | 1 | |

TABLE HAND FEED ASS'Y (FOR AH SERIES





TABLE HAND FEED ASS'Y(FOR AH SERIES)

(618-06)

| Index No. | Parts No. | Parts Name | Q'ty | Spec. |
|-----------|------------|--------------|------|-----------|
| 1 | 618-06-001 | Grip | 1 | |
| 2 | 618-06-002 | Handwheel | 1 | |
| 3 | | Cap Nut | 1 | M12 |
| 4 | | Washer | 1 | ϕ 12 |
| 5 | | Snap Ring | 1 | ϕ 16 |
| 6 | 618-06-009 | Spring Seat | 1 | |
| 7 | 618-06-010 | Spring | 1 | |
| 8 | 618-06-011 | Washer | 1 | |
| 9 | | Bearing | 2 | 6803ZZ |
| 10 | 618-06-012 | Shaft Sleeve | 1 | |
| 11 | 618-06-013 | Shaft | 1 | |
| 12 | | Key | 1 | 5x 20L |
| 13 | 618-06-014 | Gear | 1 | |
| 14 | | Pin | 1 | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

LONGITUDINAL HYDRAULIC CYLINDER ASS'Y (FOR AH SERIES)




LONGITUDINAL HYDRAULIC CYLINDER ASS'Y

(FOR AH SERIES)

(618-07)

| Index No. | Parts No. | Parts Name | Q'ty | Spec. |
|-----------|------------|-----------------------|------|--------|
| 1 | | Nut | 4 | M8 |
| 2 | | Washer | 4 | φ 10 |
| 3 | 618-07-001 | Rubber Pad | 2 | |
| 3.1 | 618-07-009 | Cylinder Supporter(R) | 1 | |
| 3.2 | 618-07-010 | Cylinder Supporter(L) | 1 | |
| 4 | | Dust Seal | 2 | DR10 |
| 5 | | Socket Head Cap Screw | 8 | M5*10L |
| 6 | 618-07-002 | Fixed Plate | 2 | |
| | | | | |
| 8 | 618-07-003 | End Cover | 1 | |
| 9 | | Oil Seal | 2 | UN10 |
| 10 | | O-Ring | 2 | P21 |
| 11 | 618-07-004 | End Cover Base | 1 | |
| 12 | | Socket Head Cap Screw | 2 | M5*16L |
| 13 | 618-07-005 | Cylinder Pipe | 1 | |
| 14 | 618-07-006 | Piston Rod | 1 | |
| 15 | | O-Ring | 2 | P21 |
| 16 | 618-07-007 | Piston | 1 | |
| 17 | | Taper Pi N | 1 | #2*20L |
| 18 | 618-07-008 | End Cover | 1 | |
| 19 | | Socket Head Cap Screw | 2 | M6*40L |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

CROSSFEED SWITCH ASS'Y (FOR AH SERIES)




CROSSFEED SWITCH ASS'Y (FOR AH SERIES)

(618-08)

| Index No. | Parts No. | Parts Name | Q'ty | Spec. |
|-----------|------------|--------------------------|------|---------|
| 1 | 618-08-001 | Limit Switch Fixed Plate | 1 | M6*6 |
| 2 | | Socket Head Cap Screw | 2 | ME-8104 |
| 3 | | Limit Switch | 2 | M4*25 |
| 4 | | Round Head Screw | 4 | M4*12 |
| 5 | | Round Head Screw | 4 | |
| 6 | 618-08-002 | Travel Bar Seat | 2 | M6*30 |
| 7 | | Socket Head Cap Screw | 2 | M6*6 |
| 8 | | SET Screw | 2 | M6*6 |
| 9 | | SET Screw | 2 | M5*5 |
| 10 | 618-08-003 | Travel Limit Bracket | 2 | |
| 11 | 618-08-006 | Handle Screw | 2 | M6*20 |
| 12 | 618-08-004 | Dog | 2 | |
| 13 | 618-08-005 | Travel Bar | 1 | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

VALVE ASS'Y



VALVE ASS'Y (FOR AH SERIES)

(618-09)

| Index No. | Parts No. | Parts Name | Q'ty | Spec. |
|-----------|-----------|-----------------------|------|---------------|
| 1. | 618-09-01 | Control Lever | 1 | |
| 2. | 618-09-02 | Handle Boss | 1 | |
| 3. | | Cross Head Cap Screw | 3 | M4*5L |
| 4. | 618-09-03 | Control Valve Plate | 1 | |
| 5. | 618-09-04 | Dust Shield | 2 | DH-14 |
| 6. | 618-09-05 | Brass Bearing | 2 | 1512 |
| 7. | | Socket Head Cap Screw | 8 | 3/16"*1-1/4"L |
| 8. | 618-09-06 | Control Shaft Cover | 2 | |
| 9. | 618-09-07 | U-Packing | 2 | UN-15 |
| 10. | 618-09-08 | O-Ring | 2 | 28.5mm*2.62mm |
| 11. | 618-09-09 | Valve Body | 1 | |
| 12. | | End Plug | 1 | 1/2"PT |
| 13. | 618-09-10 | Flow Control Shaft | 1 | |
| 14. | | Nut | 3 | M5 |
| 15. | | Socket Head Cap Screw | 2 | M6*40L |
| 16. | 618-09-11 | Fixed Ring | 1 | |
| 17. | | Socket Head Cap Screw | 1 | M6*20L |
| 18. | | Set Screw | 1 | M5*5L |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |