




Springwood Industrial, Inc.  
 2320 E Valencia Dr  
 Fullerton, CA 92831  
 Tel: 714-871-5558 Fax: 714-871-5554  
<http://www.aceronline.net>

[info@aceronline.net](mailto:info@aceronline.net)

Klim Industrial, Inc.  
 244 N. Randolphville Road  
 Piscataway, NJ 08854  
 Tel: 732-752-9100 Fax: 732-752-9101  
<http://www.aceronline.net>


[acer\\_klim@yahoo.com](mailto:acer_klim@yahoo.com)

## E-MILL 3VK RPM GAUGE ADJUST PROCEDURE



High Range Adjustment:

Adjusting RPM Gauge Procedure



Using the ENT key press 2222 then press ENT.      After high range program

High range low speed indicator	High range high speed indicator
	4500
dSPL1 → ENT →	dSPH1 →

Push the Up and Down key at the same time, then exit

Low Range Adjustment:

### Adjusting RPM Gauge Procedure

Program #	Low range low speed indicator	Low range high speed indicator
0		522
ENT → dP2 → ENT →	dS2L1 → ENT →	dSPH1 →

Using the ENT key press 522 then press ENT.

After low range program

Push the Up and Down key at the same time, then exit

### The Digital Gauge Zero Reset Procedure

Take off the cap. It will show the five buttons. Press ENT 3X then it will indicate dSPL1. For example, if the digital indicator shows “3”, enter number “-0003”, (change positive to negative) if the number is “-3”, then enter “0003”. Press the Up and Down key at the same time, then exit.

### Digital display after removing cap

