

故障原因 PLC paramenter replacement procedure

2. After updating, please check PLC's toggle is set at "RUN"!



