



Springwood Industrial, Inc.
1062 N. Kraemer Place
Anaheim, CA 92806
Tel: 714-632-9701 Fax: 714-632-9730
<http://www.aceronline.net>

info@aceronline.net

Klim Industrial, Inc.
244 N. Randolphville Road
Piscataway, NJ 08854
Tel: 732-752-9100 Fax: 732-752-9101
<http://www.aceronline.net>

acer_klim@yahoo.com

PROCEDURE TO RELOCATE AN ACER LATHE

1. Use a sling, strap or chain and loop around the machine rib in the center of machine and secure it.

OR Do as follows:

2. UNPACKING & MACHINE INSTALLATION

2-1 Unpacking

When the machine arrives,

Check first to see if the crate or container is damaged.

Open the crate and inspect for any damage to the machine or missing parts.

If you find any damage or missing parts, please contact your distributor or the appropriate insurance company immediately.

Failure to report any discrepancies or damage immediately could result in a delay or the possibility of a claim being denied.

2-2 Lifting

Please refer to figure 2-2 for unloading and moving of machine.

1. Use hanging jig to lift the lathe.
2. Locate the jig at approximately the center of the lathe.
3. Move apron and tailstock towards the end of bed to balance the weight.
4. To insure the accuracy of machine, not to jar the machine when it is placed on its foundation.
5. The backside of the machine should be at least 600mm (24") away from any wall or obstruction to have sufficient space for wiring the input power.

