

OPERATION MANUAL

MODEL: **Supra** **618AH/AHD**
 818AHD

INDEX

PAG

1. FOREWORDS.....	1
2. SAFETY PRACTICES.....	2
3. SPECIFICATIONS.....	3
4. PARTS NAME OF MACHINE.....	4
5. CONTROL PANEL.....	6
6. INSTALLATIONS.....	7
7. OPERATIONS.....	10
8. GRINDING WHEEL SELECTION GUIDE TABLE.....	11
9. CROSS OIL PRESSURE.....	16
10. REAR-FRNT MANUAL.AUTOMATIC. RAPID FEED OPERATION.....	17
11. PARTS NAME OF MACHINE (618/818 AHD).....	18
12. 618/818 AHD CONTROL PANEL.....	19
13. DEFINITION OF AHD CONTROL PANEL(OPERATION INSTRUCTION).....	20
14. GRINDING PROCEDURES IN AUTO GRINDING MODE.....	25
15. MAINTENANCE.....	26
16. TROUBLE SHOOTINGS.....	28
17. HYDRAULIC CIRCUIT DIAGRAM.....	29

FOREWORDS

This machine is built by "FORMOSA SPRINGWOOD INTERNATIONAL INC.", #202-1 SENG TSO ROAD, SENG KARNG SHARNG TAICHUNG COUNTY, TAIWAN R. O. C. with the following features:

1. ENLARGED COLUMN & BASE:
2. RIGID CONSTRUCTION OF BASE & SADDLE:
3. CARTRIDGE TYPE DIRECT DRIVE SPINDLE:
4. AUTOMATIC LUBRICATION SYSTEM:
5. **TURCITE-B WAYS:**
6. INDEXIBLE TABLE HANDWHEEL:
7. INCOPERATED TOOL CABINET:
8. ONE-PIECE SADDLE:

For your safety & machine performance, please study this manual carefully and thoroughly to assure that you understand this machine before operations. The working efficiency shall be maximized only after your careful study.

Neverthress, the manufacturer reserves the right to improve machine without any prior notice. If you have any questions, services and/or comments to our grinders, please just feel free to call your nearest distributors or advise us at the followings.

SAFETY PRACTICES

A. TO PREVENT SERIOUS BODILY INJURIES:

It is the responsibility of an employer or owner to furnish all that is needed in operations, general or specific, and presettings. They shall further carry out a comprehensive training program and closer supervision to enforce exactly the safety rules as hereunder specified.

1. This machine shall be operated merely by the personnel who received special training and have a thorough understanding of the machine characteristics, sizes and safety rules.
2. Never place any part of your body near the moving parts of machine, nor any of their areas. In case there is a need to approach the machine, all power sources led to the said unit must be shut off.
3. Never wear loose clothings could be caught or tangle in the moving parts of the machine. Moreover, do not wear gloves. All open parts of clothing, especially the cuffs shall be buckled.
4. It is mandatory to wear goggles and safety shoes.
5. Never operate or maintain the machine without proper instructions and supervisions.
6. To change or adjust the workpiece, fixture and tools, it is a must to pull the spindle to a complete stop in the first place.
7. In case a user considers the machine is having safety problems, please stop using it immediately and notify, in writing or calling the distributors.
8. IT IS A SAFETY VIOLATION TO REMOVE ANY ONE OF THE WARNING SIGNS FROM THE MACHINE.

B. SAFETY:

In order to eliminate any possible accident and upkeep the normal operations. The safety consciousness is highly essential. It applies to any other machine usages. Furthermore, general precautions are quite helpful to an accident free factory management. Meanwhile, they can invariably promote the productivity under an optimal working environment.

1. Goggles wearing.
2. Wearing safety boots.
3. Wearing hard hats and overalls. All opening parts must be buckled.
4. Do not wear gloves during machine operations.
5. Lighting around the machine shall be sufficient.
6. Do not use an air compressor to blast chips, dust off control unit or the floor of their immediate areas.
7. Operator's foot stand shall be the most solidly built one, furnished also with the fragment-proof surface.

SPECIFICATIONS

DESCRIPTIONS		MODEL			
		Supra 618AH	Supra 618AHD	Supra 818AH	Supra 818AHD
Table size		152 x 460mm 6" x 18"	152 x 460mm 6" x 18"	203 x 460mm 8" x 18"	203 x 460mm 8" x 18"
Max. grinding length	Longitudinal	460mm 18"	460mm 18"	460mm 18"	460mm 18"
Max. grinding width	Crosswise	168mm 6 5/8"	168mm 6 5/8"	228mm 9"	228mm 9"
Max. Distance From Table Surface to Spindle Centerline		460mm 18"	460mm 18"	460mm 18"	460mm 18"
Standard magnetic chuck size		152 x 460mm 6" x 18"	152 x 460mm 6" x 18"	200 x 460mm 8" x 18"	200 x 460mm 8" x 18"
Longitudinal movement of table	Max. travel, hydraulic	482mm 19"	482mm 19"	482mm 19"	482mm 19"
	Max. travel, Manual	510mm 20"	510mm 20"	510mm 20"	510mm 20"
	Table speed, infinitely variable	5-28m/min	5-28m/min	5-25m/min	5-25m/min
Cross transverse travel	★ Auto transverse increment	1-10mm 0.07"-0.4"	1-10mm 0.07"-0.4"	1-10mm 0.07"-0.4"	1-10mm 0.07"-0.04"
	★ Max. Auto transverse travel	180mm 7"	180mm 7"	238mm 9 3/8"	238mm 9 3/8"
	Max. manual transverse travel	190mm 7 1/2"	190mm 7 1/2"	250mm 9 3/4"	250mm 9 3/4"
	Handwheel per revolution	5mm 0.2"	5mm 0.2"	5mm 0.2"	5mm 0.2"
	Handwheel per graduation	0.02mm 0.0005"	0.02mm 0.0005"	0.02mm 0.0005"	0.02mm 0.0005"
	Wheelhead vertical infeed	Automatic infeed	—	0.001-0.04mm 0.00005"-0.002"	—
	Step feed	—	0.001mm 0.00005"	—	0.001mm 0.00005"
	■ Rapid travel, Approx.	60HZ, 280mm/min 50HZ, 240mm/min	60HZ, 280mm/min 50HZ, 240mm/min	60HZ, 280mm/min 50HZ, 240mm/min	60HZ, 280mm/min 50HZ, 240mm/min
	Slow travel, Approx.	—	6mm/min	—	6mm/min
	Handwheel per revolution	1mm 0.05"	1mm 0.05"	1mm 0.05"	1mm 0.05"
	Handwheel per graduation	0.005mm 0.0001"	0.005mm 0.0001"	0.005mm 0.0001"	0.005mm 0.0001"
Grinding spindle drive	Speed	60HZ, 3450R.P.M. 50HZ, 2850R.P.M.	60HZ, 3450R.P.M. 50HZ, 2850R.P.M.	60HZ, 3450R.P.M. 50HZ, 2850R.P.M.	60HZ, 3450R.P.M. 50HZ, 2850R.P.M.
	Power Rating	1.5HP	1.5HP	2.0HP	2.0HP
Standard grinding wheel	Diameter	203mm 8"	203mm 8"	203mm 8"	203mm 8"
	Width	12mm MAX 19mm 1/2" MAX 3/4"	12mm MAX 19mm 1/2" MAX 3/4"	12mm MAX 19mm 1/2" MAX 3/4"	12mm MAX 19mm 1/2" MAX 3/4"
	Bore	31.75mm 1 1/4"	31.75mm 1 1/4"	31.75mm 1 1/4"	31.75mm 1 1/4"
	Hydraulic motor	Power Rating	1HP x 6P	1HP x 6P	1HP x 6P
Crossfeed motor	★ Power Rating	1/6HP x 6P	1/6HP x 6P	1/6HP x 6P	1/6HP x 6P
Elevating motor	■ Power Rating	40W x 4P	40W x 4P	40W x 4P	40W x 4P
Floor space	Total space required	1810x1133x1660mm 71" x 45" x 65"	1810x1133x1660mm 71" x 45" x 65"	1810x1285x1680mm 71" x 50 1/2" x 66"	1810x1285x1680mm 71" x 50 1/2" x 66"
Weights	Net weight, Approx.	820KGS 1804LBS	820KGS 1804LBS	1020KGS 2244LBS	1020KGS 2244LBS
	Gross weight, Approx.	970KGS 2134LBS	970KGS 2134LBS	1190KGS 2618LBS	1190KGS 2618LBS
Rated power, approx.		2.5HP	2.5HP	3.0HP	3.0HP
Packing dimensions	L x W x H	1500x920x1850mm 59" x 36" x 73"	1500x920x1850mm 59" x 36" x 73"	1500x1040x1970mm 59" x 41" x 73 1/2"	1500x1040x1970mm 59" x 41" x 73 1/2"

NOTE: 1. The manufacturer reserves the right to modify the design, specifications, mechanisms, etc., to improve the performances of the machine without notice. All the specifications shown above are just for reference.

PARTS, NAME OF MACHINE:






Fig.1

1.	Hydraulic motor	14.	Table
2.	Pilot operated directional valve	15.	Saddle
3.	Spindle motor	16.	Cross handwheel
4.	Spindle	17.	Longitudinal travel adjuster
5.	Oil gauge	18.	Base
6.	Oil hole	19.	Tool cabinet
7.	Pressure regulator	20.	Downfeed handwheel
8.	Oil separator	21.	Cross speed control
9.	Oil tank	22.	Cross handwheel
10.	Wheel guard & spindle	23.	Control panel
11.	Grimding wheel	24.	Coolant & dust switch
12.	Column	25.	Electrical panel
13.	Cross travel adjuster	26.	
		27.	Lubricating oil sight gage



8.	Motor start button	Emergency stop switch
9.	Micro longitudinal manual adjusting button (818AH)	Spindle-on switch
		Spindle-off switch
10.	Longitudinal change-over switch	Rapid up/down switch
		Pilot lamp
11.	Longitudinal semi-auto & automatic change-over switch	Table automatic & manual
		Motor stop button

CONTROL PANEL: (618AH)



1.	Emergency stop switch	8.	Motor start button
2.	Spindle-on switch	9.	Micro longitudinal manual adjusting button (618AH)
3.	Spindle-off switch		
4.	Rapid up/down switch	10.	Longitudinal change-over switch
5.	Pilot lamp		
6.	Table automatic & manual		
7.	Motor stop button	11.	Longitudinal semi-auto & automatic change-over switch

INSTALLATIONS

A. Lifting:




Fig. 3

Use the following facilities to lift the machine:

1. Overhead crane
2. 2 pcs of cables, each at $\phi 12.7\text{mm}(\frac{1}{2}'') \times 1830\text{mm} (72'')$ long.
3. 1 steel bar

NOTE: 1. Machine must always be kept balanced during lifting.
2. Place protecting material, such as hard cardboard, wooden wedges, on any part of machine that might be contacted by the cables.
3. Cables must be placed firmly at both ends of the steel bars to prevent the wires from slipping off.

B. Cleaning:

Machines are applied with rust preventive in the manufacturer before packing. Please clean the coating with solvent solution before operations.

C. Levelling:




Fig. 4

Clean the table surface thoroughly and use 2 spirit levels, one on longitudinal direction while the other one on cross direction. Adjusting the 3 levelling screws at the base till the readings is $0.02\text{mm}/1000\text{mm}$ ($0.001^{\circ}/4\text{FT}$) on both longitudinal and cross directions. Then lock the nuts on the screws and check the readings again till $0.02\text{mm}/1000\text{mm}$.

When levelling the machine, a solid floor or anti-vibration pads are highly recommended to prevent any rocking during grinding.

D. Wheel extracting:




Fig. 5

E. Oil passage installation diagram:

1. Please according to this diagram to fix the position of column and oil tank.
2. Oil pipe connection: In comply with mark on oil pipe and oil tank A→A . B→B. P1→P1. T→T P→P. then tight them by a wrench for avoid oil leakage.
3. Fromc(oil hole) put the oil into oil pressure tank until the oil scale on $\frac{1}{3} \sim \frac{2}{3}$. the capacity of oil about 18 gallon (72l).
4. Please fill in hydraulic tank with any of the following oils after installation but before starting hydraulic motor.
5. Please change hydraulic oil after 3 months use in the begining and then once every 6 months.
6. Recommended oils:

SUN	SUNVIS 916	SHELL	TELUS 32
SHOWA	A-R32	MOBIL	D.T.E. 24
ESSO	NUTO H32	TEXACO	LUBE TAC #2
BP	ENERGOL HLP 32	ARAL	VITAM GF 32




Fig.6

OPERATIONS

A. Power connecting:

Machines would be prewired to 220V at the manufacturer unless otherwise specified by the purchaser. Please check the panel voltage against main supply before connecting the cable through a hole from the bottom of electrical cabinet to the terminals.

B. Test of motor rotating:

After power connecting, turn on the main power switch to check if the rotation of the motor is clockwise. If not, just reconnet cables by changing any two of the wires from the primary supply.

C. Selection of grinding wheel:

Please refer to the guide table of grinding wheels. (Fig. 5)

D. Standard wheel markings: (Fig. 6)

Grinding wheel selection guide table

Grinding wheel selection guide table(Surface grinding)

	Materials to be ground	Hardness(Rockwell)	Wheel specification
Carbon steel	steel plate carbon steel	under HRC 25	WA A 46H
	forged carbon steel cast carbon steel	above HRC 25	WA 40J
Alloy steel	Ni,Cr steel Ni,Cr,Mo steel Cr steel Cr,Mo steel	under HRC 55	WA 46J
	Al,Cr,Mo steel high carbon, alloy	above HRC 55	WA 46I
	Alloy cast steel tool carbon steel.	HRC 55	WA 46I
tool steel	High speed steel	under HRC 60	WA 46I
	Alloy tool steel	above HRC 60	WA 46H
stainless steel	Stainless steel		WA 46I
	antiheat steel		WA 36J
cast iron	grey cast iron		C 46J
	special cast iron		GC 46I
	cold rolling cast iron		GC 46I
	malleable cast iron		WA46K
nonferrous metal	brass		C 30J
	bronge		A 46K
	aluminum alloy		C 30J
	sintered carbide		CC60-100HI

Fig. 7

Standard wheel markings

1 - A - 305x25x127

WA

46

K

8

V

7N

2000M

Form	Faces	size	Abrasive type	Grain size		Grade	Structure	Bond type	Maker code	Max. R.P.M.
1. Straight (plain)	A	DxWxB	A	10	220	AO	0	V	maker	1400
2. Cylindrical	B	Dia:D	WA	12	240	BP	1	B	own	1500
				14	280	CQ	2	R	recor	1700
3. Relieved one side	C	width:W	PW	16	320	DR	3		for	2000
				20	400	ES	4	S	the	2400
4. Relieved two-side	D	Bore:B	C	24	500	FT	5	E	wheel	2700
				30	600	GU	6			3000
5. Single recess	E		CC	36	700	HV	7			3600
6. Straight cup	F		AZ	46	800	IW	8			4300
				60	1000	JX	99			4800
7. Double recess	M			80	1200	KY	10			
9. Double cup	N			100	1500	LZ	11			
				120	2000	M	12			
				150	2500	N	13			
				180	3000		141			
	P				4000		15			

Fig. 8

S:Silicate

V:Vitrified

E:Shellac

B:Resinoid(Synthetic resin)

R:Rubber

NOTE:To obtain a good surface finish and accuracy, a appropriate grinding wheel must be used. The followings must be considered.

1. Required accuracy and surface finish.
2. Contact area during grinding.
3. Special feature of grinding operations.
4. Wheel speed.
5. Feed rate

Dressing of wheel:

- Dress the wheel with diamond dresser when it is filled with chips or when a poor surface finish is obtained.
- The installation of a diamond dresser should be inclined to an angle $5-10^\circ$ from the wheel centerline. When the diamond bit become dull, just turn the diamond collar to the desired angles, shown as Fig. 9.




Fig. 9

- Due to the hardness or weakness of the diamond. Do not dress the wheel too deep at one time. The correct way to dress the wheel is to start from the center of the wheel.

- Recommended dressing speeds

$$F = \frac{d \times N}{2.5 \times 1000}$$

F: crossfeed speed (mm/min).

d: grind diameter (μ)

N: R.P.M. of wheel

grain size	10	12	14	16	20	-	24	30	36	46	54	60	70	80	90	100	120	-	150	180	220
grain diameter (mm)	2.0	1.7	1.4	1.2	1.0	0.8	0.7	0.6	0.5	0.35	0.3	0.25	0.2	0.17	0.14	0.12	0.1	0.08	0.07	0.06	0.05

Example: The grind wheel diameter 510mm, grain size 60, velocity 2000m/min,

dressing speed 124.8mm/min. (4.9 IPM)

$d = 0.25\text{mm} = 250\mu$ (grain size 60, refer to the table, $d = 0.25\text{mm}$)

$N = 1248 \text{ r.p.m.} (N = \frac{\text{velocity of wheel}}{\pi \times D})$

$$(N = \frac{2000 \times 11000}{\pi \times 510} \approx 1248)$$

$$F = \frac{d \times N}{2.5 \times 1000} = \frac{250 \times 1248}{2.5 \times 1000} = 124.8 \text{ mm/min (4.9 IPM)}$$

e. Balance of grinding wheel

To obtain fine surface finish and accuracy, the grinding wheel must be checked and rebalanced periodically. (Fig 10) A standard and balanced grinding wheel is supplied with the grinder from manufacturer. Please follow the following procedures for balancing.





Fig. 10

1. Let the wheel roll freely on the stand to find out it's gravity center "S" and mark it with chalk.
2. Insert a balancing block on the opposite side "G" of "S", rotate the wheel 90° to find out "S" or "G" side is heavier.
3. Insert the second balancing block at heavier side "K" which are of the same arc from "G" point.
4. Rotate the wheel 90° to check the balance of the wheel. If it is still out of balance, readjust 2 blocks "K" position until grinding wheel is really balanced. When grinding workpiece with different materials, just change the wheel with its flange together to save time required for balancing the wheel.








Fig. 11

CROSS OIL PRESSURE: (Fig.11)

- A. The proper longitudinal travel for grinding process is limited within 15 - 25 mm (1/2" - 1") over workpiece by grinding wheel as shown in fig.11(a). Longitudinal travel relates to the position of the two table reverse dogs (fig.11(b)).
- B. Moving the table by cross handwheel: Fig.11(c)
1. At first turn the oil switch (7) off or turn the change-over switch of table at  (6).
 2. Press the cross handwheel matches with the gears cross movement and the table will cross movement, too. (When the hand loosen the handwheel, it will back to original.)
- *CAUTION: Disengage table handwheel before operating machine hydraulically.
- C. Control the speed of cross oil pressure movement:
1. Turn on the oil pressure motor (8) and turn table switch (6) at .
 2. Adjust the handle (P4. 21) to fast speed on clock wise direction. On the other hand, turn it on counter clock wise direction.





Fig. 12


1.	Rear travel safety limited	5.	Front travel switch
2.	Rear travel moving set	6.	Front moving fixed handle
3.	Rear moving travel fixed handle	7.	Front travel moving set
4.	Rear travel switch	8.	Front travel safety limited

Rear-Front manual.Automatic.rapid feed operation:(Fig.12)


A.Munal:Turn switch (11) at  then turn the hand wheel directly.

B.Rapid:Please turn the halld wheel into inside direction (it will avoid the operator hurt dy rapid or automatic) then operated (10) for cross rapid movement directly.

C.Automatic:


- 1.At firt turn the handwheel into the inside direction.
- 2.Turn switch(11) ai 
- 3.According to the speed of cross oil pressure to control it.when the table moving to ihe end of both sides it wi (11) forward or retreat automatic.
- 4.The incremet length of cross movemene is adjusted by no(9)in control panel (Ref to Fig.2)
- 5.Grinding middle plate (10) and also have forcible change dirctionfunction forimprove the grinding effect.

PARTS NAME OF MACHINE (818AHD)



1	*Parallel dressing attach.	8	*Splash guard
2	Dust collecting nozzle	9	Cross saddle lock
3	Hydr. table travel adjust	10	Control panel
4	Coolant/Dust system ON/OFF	11	Table speed control unit
5	Electric box	12	Oil thermometer/gauge
6	Vertical feed handwheel	13	Hydraulic oil tank
7	*Coolant nozzle		

*Items marked with asterisk are optional at extra cost



DEFINITION OF AHD CONTROL PANEL (OPERATION INSTRUCTION)

NO	ELECTRICAL CODE NO	SYMBOLIC DEFINITION	DESCRIPTION
1		Power indicator lamp	Light-on represents normal power supply
2		Emergency stop push-button	To stop all motors and functions
3		Spindle start push-button	To start the spindle(wheel head)
4		Spindle stop push-button	To stop the spindle(wheel head)
5		Hydraulic start push-button	To start hydraulic system for table reversal motion
6		Hydraulic stop push-button	To stop hydraulic system
7		Rapid in/out switch	To select rapid inward or outward saddle motion In auto surface mode, the operator can use this switch to toggle the proceeding direction revrsely.
8		Variable step increment of crossfeed selector	To select the required step increment of crossfeed in auto surface mode
9		Wheelhead slow-up push-button	a) Push push-button (9) to begin slow-up motion on wheelhead b) Push push-button (9) & 10 together to begin rapid-up motion on wheelhead
10		Rapid up/down push-button	a) Push push-button (9) & (10) together to invoke rapid-up motion on wheelhead b) Push push-button (11) & (10) together to invoke rapid-down motion on wheelhead
11		Wheelhead slow-down push-button	a) Push push-button (11) to invoke slow-down motion on wheelhead b) Push push-button (11) & (10) together to invoke rapid-down motion on wheelhead
12		Downfeed jogging push-button	In inches, 0.00005" downfeed increment/ per push In metric, 0.001mm downfeed increment/ per push

DEFINITION OF AHD CONTROL PANEL (OPERATION INSTRUCTION)

NO	ELECTRICAL CODE NO	SYMBOLIC DEFINITION	DESCRIPTION
13		Grinding mode selector	<p>There are four selections as follows:</p> <p>A. Manual surface mode: In this mode, (a) When light of button (14) is on, below functions are available: 1) Rapid in/out by push-button (7) 2) Rapid/slow up/down by push-button (9), (10), (11) 3) Jogging by push-button (12)</p> <p>(b) When light of button (15) is on, and the the table has been started by turning table speed control and the required step increment of crossfeed has been set on selector (8), 1) Table running direction toggle by switch (7) 2) Workpiece approaching by push-button (9), (10), (11) 3) Jogging by push-button (12)</p> <p>B. Auto surface mode: In this mode, (a) When light of push-button (14) is on, below functions are available: 1) Rapid in/out by push-button (7) 2) Jogging by push-button (12)</p> <p>(b) When light of push-button (15) is on, autot downfeed surface mode is already invoked, and auto downfeed will start on the access of table and saddle motion</p> <p>The wheelhead is raised up and all motors stopped automatically upon completion of spark-out passes</p> <p>1) Step increment of crossfeed by selector (8) 2) Table running director toggle by switch (7) 3) Jogging by push-button (12) 4) Selector (16), (17), (19), (20), (22), (23) may be adjusted in the cycle, but the change will effect the current cycle.</p> <p>C. Manual plunge mode: In this mode,</p>

DEFINITION OF AHD CONTROL PANEL (OPERATION INSTRUCTION)

NO	ELECTRICAL CODE NO	SYMBOLIC DEFINITION	DESCRIPTION
			<p>Auto step feed, rapid in/out on cross travel are disabled, only manual feed on cross travel available.</p> <p>1) Jogging by push-button ⑫ 2) Rapid/slow up/down by push-button ⑨, ⑩, ⑪</p> <p>D. Auto plunge mode: In this mode,</p> <p>a) When light of push-button ⑮ on, auto downfeed plunge mode is already invoded, and auto downfeed will start upon the access of table strokes.</p> <p>The wheelhead is raised and all motors are auotmatically stopped upon completion of spark-put passes.</p> <p>1) Jogging by push-button ⑫ . 2) Selector ⑯, ⑰, ⑱, ⑳, ㉑, ㉒ may be adjusted in the cycle, and the cange will effect the current cycle.</p> <p>b) When light of push-button ⑭ on,</p> <p>1) Jogging by push-button ⑫ . 2) Rapid up/down, rapid in/out not available.</p>
14		Reset push-button	To cancel the previous setting on selector ⑬, which have been in effect.
15		Set push-button	To invoke the current setting on selector ⑬, put the setting into effect.
16		Elevation amount selector	To set the required amount to be elevated upon the completion of spark-out passes.
17		Total amount setting push-button	<p>To invoke the current setting on total amount selector ㉑ .</p> <p>The setting on total amount selector ㉑ won't re-effect the current downfeed</p>

DEFINITION OF AHD CONTROL PANEL (OPERATION INSTRUCTION)

NO	ELECTRICAL CODE NO	SYMBOLIC DEFINITION	DESCRIPTION
			<p>Useful occasion:</p> <p>After the workpiece changed and the required total downfeed amount selected, push this push-button as confirmation of the current setting.</p> <p>pushing this push-button during the proceeding downfeed cycle will change the proceeding total downfeed amount</p>
18		Zero downfeed indicator lamp	The lamp light goes on on completion of downfeed increments, preset spark-out passes will be proceeded at this time.
19		Sparks-out passes selector	To set the required spark-out passes, which will be proceeded upon completion of downfeed increments.
20		Total downfeed amount (increments) selector	To set the required downfeed increments for either auto plunge mode or auto surface mode.
21		Downfeed step increment display window	<p>The display window shows the current downfeed increment being proceeded.</p> <p>Actual downfeed step increment</p> <p>=displayed value X 0.001mm(in metric),</p> <p>=displayed value X 0.00005"(in inches)</p>
22 23		Downfeed step increment selector	<p>In metric:</p> <p>Selectable downfeed step increment goes from 0.001,0.002,0.003,.....,0.039, 0.040mm(40 steps).</p> <p>Downfeed step increment= selected value on selector ② X 0.001mm + selected value on selector ③ X 0.001mm</p> <p>In inches:</p> <p>Selectable downfeed step increment goes from 0.00005", 0.00010",....., 0.002"(40 steps).</p> <p>Downfeed step increment= selected value on selector ② X 0.00005" + selected value on selector ③ X 0.001mm</p>

GRINDING PROCEDURES IN AUTO GRINDING MODE

NO	ACTION	FUNCTION SWITCH
1	Rapid down approaching	Switch to manual surface/plunge mode on selector switch (12), then push button (10, 11) at the same time
2	Slow down approaching	Switch to manual surface/plunge mode on selector switch (13), then push button (11)
3	Jogging	Push button (12)
4	Auto increments	<p>Switch to auto surface/plunge mode push button (15) till light of it on (in auto surface mode, check selector switch (8) not on zero-position).</p> <p>Then access auto downfeed cycle. During auto downfeed cycle, the machine will lower the wheelhead according to the increment amount set on selector (22), (23) and the total downfeed amount set on selector (20).</p> <p>*Real downfeed amount is relative to the setting on selector (20) and the setting on vertical handwheel.</p>
5	Zero-downfeed spark-out	Execute spark-out passes relative to selector button (19).
6	Table parks automatically	The table parks automatically at table end and all motors are stopped
7	Wheelhead rise-up	Wheelhead rises relative to selector switch (16).
8	Repeat	<p>After replacing workpieces for grinding, push-button (5) to start the hydraulic system, push push-button (3) to start the spindle, then push push-button (15) to access auto downfeed cycle (step 4 - 8).</p> <p>The operator may need to re-approach the workpiece after the workpiece is changed, the elevation amount after auto grinding cycle is relative to selector switch (16) and adjust may be needed till proper elevation amount obtained.</p>

MAINTENANCE

A. Lubrication: (Fig.13)




Fig.13

- | | |
|------------------------------|-------------------------|
| (A). Elevating leadscrew | (B). Cross leadscrew |
| (C). Long. & cross slideways | (D). Oil draining valve |
| (E). Oil distributor | |

B. This machine is equipped with "AUTO LUBE SYSTEM" as standard on rear part of the column. Once the spindle rotates the lubricant will flow over column, saddle & table automatically and consecutively until the spindle stops. Please change the lubricant every 3 months or refill the reservoir up whenever is less than the half, with the following suggested oils

C. RECOMMENDED OILS:

- Mobil ISO VG32 (SW32)
- FBK OIL RO#32
- ESSC FEBI SK#53



MAINTENANCE

1. Clean the machine daily after jobs but do not use compressed air.
2. Do not allow dust or chips get in the slide ways. To do so, it is suggested to use a dust unit during dry grindings.
3. The spindle motor should be cleaned with a vacuum yearly. At no time should you use compressed air to clean motor.
4. Check all the circuit connections yearly and test them whenever necessary.
5. Check machine level at least once a year
6. Stop and check the machine whenever any abnormal noise occurs.

TROUBLE SHOOTINGS

Problem	Cause	Remedy
Frequent wave on the surface of the work-piece	Vibration of the machine	<ol style="list-style-type: none"> 1. Check the level of the machine and the sturdiness of the floor. 2. Check the spindle.
	Grinding wheel is unbalanced.	<ol style="list-style-type: none"> 1. Dress the wheel again. 2. Balance the wheel.
	Wheel is too hard	<ol style="list-style-type: none"> 1. Use a soft wheel. 2. Use a rough wheel. 3. Reduce the feed amount.
Minor scratch on the surface	Improper operation	<ol style="list-style-type: none"> 1. Dress the wheel. And make sure that the wheel is parallel with work piece. if not, adjust the parallel dresser. 2. Slow the crossfeed speed. 3. Block in the work piece to prevent movement.
	Improper dressing the wheel	<ol style="list-style-type: none"> 1. Slow the dressing speed. 2. Tighten the dresser well. 3. Use the proper dressing speed. 4. Don't dress too deep at a time.
Burning spots and cracks	Improper operation	<ol style="list-style-type: none"> 1. Reduce the feeding amount. 2. Use the proper crossfeed speed.
	Improper heat treatment	Re-heat treat
	Unsuitable grinding wheel	<ol style="list-style-type: none"> 1. Dress the wheel finely and frequently. 2. Use a softer and rougher wheel.
Poor grinding ability, and wheel clogs and workpiece shown Burn	Wheel is too hard	<ol style="list-style-type: none"> 1. Increase the table speed and crossfeed speed. 2. Slow the wheel revolution, (reduce the wheel diameter or width). 3. Use the sharp diamond to dress the wheel. 4. Chose a rougher wheel.
Wheel dulls and the grit fall off	Wheel is too soft	<ol style="list-style-type: none"> 1. Reduce the table speed and crossfeed speed. 2. Increase the wheel revolution speed, or enlarge the wheel diameter, if possible 3. Dress the wheel lightly and repeatedly.

HYDRAULIC CIRCUIT DIAGRAM



A.	Hight pressure hose	3/8" x 950L
B.	"	3/8" x 1350L
P.	"	3/8" x 950L
P1.	"	"
T.	"	"
1.	Hydraulic system motor	1HP/6P
2.	Directonal valve with	
2-1.	Directional valve	
2-2.	Solenoid control valve	
3.	Strainer	
4.	Presure reducing valve	
5.	Hydraulic circuit plate	
6.	Positive vane pump	16cc/REV
7.	Volume control valve to regulate the longitudinal speed of grinder	
8.	Longitudinal cylinder	



PARTS LIST

MODEL: **Supra 618AH/AHD**
818AHD

INDEX

PAGE

1. TABLE.....	32
2. SADDLE.....	35
3. BASE(618AH & 618/818 AHD).....	39
4. BASE(618/818).....	44
5. COLUMN.....	48
6. SPINDLE.....	52
7. AUTO ELEVETING MECHNISM(618/818 AHD).....	55
8. ELECTRICAL BOX (618/818 AHD).....	59



AUTO SURFACE GRINDING MODE

AUTO PLUNGE GRINDING MODE

Downfeed increment occurs at the same as cross direction reverses.

Crossfeed is not moved, downfeed increment occurs at the time that table reverses from right end.

After grinding cycle completed, table parks, wheelhead stops, and rises up automatically

After grinding cycle completed, table parks, wheelhead stops and rises up automatically.

inches


Selectable downfeed step increment goes from 0.0002", 0.00010", 0.00005", 0.000025", 0.0000125" (40 steps).

Downfeed step increment = selected on selector 23 X 0.00025" + selected value on selector 23 X 0.001mm


INDEX

TABLE

QHA 8187818 2 HAB78



NO.	PART NO.	DESCRIPTION	Q'TY	SIZE	REMARKS
1.	100809 100822	Splash guard	1		A B
2.		Wing nut	2	1/4"	
3.		Plate washer	4	φ 6	
4.		Cross head screw	4	M6x25L	
5.	100810	Rear splash plate	1		
6.	100810	Rear splash plate	1		
7.		Cross head screw	4	M6x25L	
8.		Plate washer	1	φ 6	
9.	100811	Front splash guard	1		
10.	100811	Front splash plate	1		
11.	100808 214004	Left-hand splasher	1		A B
12.		Hex screw	2	M6x25L	
13.		Plate washer	2	φ 6	
14.		Hex nut	2	3/8"	
15.		Plate washer	2	φ 10	
16.	100432-1	T-nut	2		
17.	100401 224001	Table	1		A B
18.	200407 224002	Left-end cover	1		A B
19.		Cross head screw	8	M4x16L	
20.	200431	Side cover of induction rail	2		
21.	200425	Longitudinal induction rail	1		
22.		Sock head cap screw	4	M5x14L	
23.	200432	Locking block of sensor-detected sheet	2		
24.	200434	Longitudinal sensor-detected sheet	2		



SADDLE

NO.	PART NO.	DESCRIPTION	Q'TY	SIZE	REMARKS
1.		Cup nut	1	M12	
2.		Washer	1	φ12	
3.	100430	Knob	1		
4.	100422	Handle wheel	1		
5.	200410-1 224004	Transmit shast	1		A B
6.		Wood ruff key	1	5x5x20L	
7.		Wood ruff key	1	4x4x12L	
8.		Thrust bearing	1	51103	
9.		Needle bearing	1	DHK1712	
10.					
11.	200402-1 224005	Shaft sleeve	1		A B
12.	200405	Gear	1		
13.	200406	Washev	1		
14.		Inner hex screw	1	M5x12L	
15.	200317	Limit ring	2		A,B
16.	200318	Stroke seat	2		A,B
17.	200319	Fixing handle	2		A,B
18.		Hex screw	2	M6x60L	A,B
19.	200316 223004	Cross guide rod	1		A B
20.	200315	Fixing pin	2		C,D
21.		Cross limit switch	2	TEND TZ8104	C,D
22.		Inner hex screw	2	M6x6L	C,D
23.	200301 223001	Saddle	1		A B
24.					


A:618AH/AHD

B:818AHD

SADDLE

NO.	PART NO.	DESCRIPTION	Q'TY	SIZE	REMARKS
25.					
26.		Inner hex screw	2	M6x14L	
27.	200615	Throttle valve seat	1		
28.		Hex screw	2	M6x22L	
29.		Hex screw	4	3/16"x3/4L	
30.	101014	Throttling indicator plate	1		
31.		Cross head screw	2	M4x8L	
32.	200605	Handle seat	1		
33.	200606	Handle	1		
34.		Hex nut	4	M12	
35.		Plate washer	4	φ12	
36.		Spring washer	8	φ25xφ12.2 x0.9	
37.		Anti-abrassive ring	2	1410DU	
38.		Hex screw	8	M4x10L	
39.	200613	Sealing plate	2		
40.		Protecting oil ring	2	DH-14	
41.	200611	Sealing seat	2		
42.		O-ring	2	P28	
43.		Seal	4	UHS14	
44.	200610 -1	Cylinder head	2		
45.		O- ring	2	P29	
46.	200607	Cylinder	1		
47.	200608-1	Piston rod	1		
48.		Piston ring	4	FD21	

BASE (618AH/AHD)
818AHD



BASE (618AH/AHD)
(818AHD)


NO.	PART NO.	DESCRIPTION	Q'TY	SIZE	REMAFKS
1.		Hex screw	1	M4x20L	
2.	100217	Locking nut	1		
3.	100237	Handle	1		
4.	100415	Washer	1		
5.	100318	Cross handle wheel	1		
6.	100319 100320	Scale ring	1	MM INCH	
7.	100218	Key-screws	1		
8.	100314	Bearing seat	1		
9.	100321	Indicating plate	1		
10.		Cross head screw	1	M5x8L	
11.		Hex screw	3	M5x25L	
12.	100317	Sleeve	1		
13.		Bearings	2	6202ZZ	
14.					
15.	100315-1	Washer	1		
16.	200307-1 200308-1	Cross transfer shaft	1	MM INCH	A
16.	223002 ^A _B	"			B
18.		Setting key	1	5x5x12L	
19.	100324	Washer	1		
20.		Cross head screw	2	M4x10L	
21.	100323	Protect plastic cover	1		
22.	100324	Ring washer	1		
23.		Cross head screw	2	M4x10L	
24.	100305-1 100306-1	Tront t-thread nut	1	MM INCH	

BASE (618AH/AHD)
818AHD

NO.	PART NO.	DESCRIPTION	Q'TY	SIZE	REMAFKS
25.		Hex screw	4	M5x20L	
26.	100307 -1 100308 -1	T-thread nut	1	MM INCH	
27.					
28.	100309 -1	Nut seat	1		
29.		Hex screw	4	M8x45L M8x50L	A B
30.					
31.					
32.	200306-1 223003	Connecting shaft	1		A B
33.		Setting Key	1	5x5x16L	
34.	200321	Internal six-Spline sleeve			
35.		Bearings	2	6007Z	
36.	200314-1	Bearing sleeve	1		
37.	200305-1	Bearing seat	1		
38.		Hex screw	4	M8x25L	
39.	200309	Timing belt pully	1		
40.	200320	Timing belt	1		
41.	200311	Locking nut	1		
42.		Inner hex screw	3	M6x12L	
43.	200304	Motor supporter	1		
44.		Hex screw	6	M8x40L	
45.		Cross morement motor	1	220v-40w 516A	
46.	200303	Motor fixing plate	1		
47.		Hex head	3	M6x16L	
48.		Plate washer	4	ø8	

618AH/AHD)
BASE 818AHD

NO.	PART NO.	DESCRIPTION	Q'TY	SIZE	REMAFKS
49.		Hex screw	4	M8x20	
50.	200310	Timing belt pully (small)	1		
51.	200312	Ring washer	1		
52.		Hex screw	1	M4x14L	
53.	100501 215001	Base	1		A B
54.		Hex screw	4	M16x60L	
55.	100502	Door	1		
56.		Cross head screw	5	M5x10L	
57.	100504	Eye bolt	4		
58.	100505	Levelling plate	3 5		A B
59.		Hex nut	3 5	M22	A B
60.	100506	Levelling plate	3 5		A B
61.	100322	Oil cover	1		
62.	100302 213003	Shaft cover	1		A B
63.		Cross head screw	6	M5x10L	
64.		Washer	6	φ5	
65.	100501 215001	Cabinet	1		A B
66.	200901	Electric box	1		
67.	200902	Electric assemole plate	1		
68.	101012-1	Control pannel	1		
69.	100903	Fixing plate	1		
70.	200901-1	Pressure button	1		
71.		Cross head screw	1	M5x10L	
72.		Hex screw	4	M8x20L	




BASE (618H)

NO.	PART NO.	DESCRIPTION	Q'TY	SPECIFICATION	REMARKS
1.		Lock screw	1	M4x20L	
2.	100217	Lock nut	1		
3.	100232	Knob	1		
4.	100415	Washer	1		
5.	100318	Handwheel	1		
6.	100319 100320	Handwheel dial	1	MM INCH	
7.	100218	Fix pin	1		
8.	100314	Bearing seat	1		
9.	100321	Indicator	1		
10.		Cross head screw	1	M5x8L	
11.		Socket screw	3	M5x25L	
12.	100317	Collar	1		
13.		Ball bearing	2	6202ZZ	
15.	100315 -1	Outer spacer	1		
16.	100303 100304	Cross leadscrew	1	MM INCH	
16.	213002 ^A _B	Cross leadscrew	1	MM INCH	
17.		Setting key	1	5 x 5 x 12L	
18.	100324	Fixed ring	1		
19.		Cross head screw	2	M4 x 10L	
20.	100323	Telescopic cover	1		
21.	100324	Fixed ring	1		
22.		Cross head screw	2	M4 x 10L	
23.	100305 -1 100306 -1	Leadscrew nut	1	MM INCH	
24.		Socket screw	4	M5x20L	

BASE (618H)

NO.	PART NO.	DESCRIPTION	Q'TY	SPECIFICATION	REMARKS
25.	100307 -1 100308 -1	Leadscrew nut	1	MM INCH	
26.					
27.	100309-1	Leadscrew seat	1		
28.		Socket screw	4	M8x45L M8x50L	
29.					
30.					
31.	100322	Tank cover	1		
32.	100302 213003	Leadscrew metal cover	1		
33.		Cross head screw	6	M5 x 10L	
34.		Washer	6	ø5	
35.	100501 215001	Base	1		
36.	100502	Door of tool cabinet	1		
37.		Cross head screw	5	M5 x 10L	
38.	100506	Levelling block	3 5		
39.		Hex nut	3 5	M22	
40.	100505	Levelling screw	3 5		
41.	100504	Lifting bolt	4		
42.	200901	Control box	1		
43.	100903	Switch bracket	1		
44.		Cross head screw	2	M5 x 10L	
45.	200901-1	Door lock	1		
46.		Socket screw	4	M8x20L	
47.	200902-1	Electrical board	1		
48.		Socket screw	4	M6x20L	




COLUMN

NO.	PART NO.	DESCRIPTION	Q'TY	SPECIFICATION	REMARKS.
1.		Round head screw	8	M6x20L	
2.	100221 212002	Front guard	1		A B
3.	100222 212004	Front guard	1		A B
4.	100223 212005	Front guard	1		A B
5.	100224 212006	Front guard	1		A B
6.	100225 212008	Front guard	1		A B
7.	100226 212008	Front guard	1		A B
8.	100201	Column	1		
9.		Round head screw	2	M4x8L	
10.	100219	Indicator	1		
11.	100220	Top cover	1		
12.		Socket head screw	2	M6x85L	
13.		Round head screw	8	M4x8L	
14.		Round head screw	4	M4x10L	
15.	100227	Plate seat .	1		
16.	100228	Plate seat	1		
17.	100204 100205	Leadscrew nut	1	MM INCH	
18.		Hex. screw	2	M6x20L	
19.	100202 100203	Elevating leadscrew	1	MM INCH	
20.		Setting key	1	5x5x15L	
21.	100111	Lock nut	1		
22.		Socket screw	2	M5x8L	
23.		Thrust needle bearing	1	ANK1730 AS1730, CS1730	
24.	100207	Bearing seat	1		

NO.	PART NO.	DESCRIPTION	Q'TY	SPECIFICATION	REMARKS
25.		Hex. screw	4	M5x15L	
26.		Thrust ball bearing	1	51103	
27.	100209	Bevel gear	1		
28.	100208	Washer	1		
29.		Socket screw	1	M6x16L	
30.	100210	Pinion gear	1		
31.		Taper pin	1	#1x27L	
32.	100235	Height pad	1		
33.	100213	Shaft seat	1		
34.		Hex. screw	2	M6x65L	
35.	100211-1	Shaft	1		
36.		Setting key	1	4x4x12L	
37.		Ball bearing	2	6002NR	
38.					
39.					
40.	100218	Bolt	1		
41.	100215 100216	Index disc	1	MM INCH	
42.	100231	Hand wheel	1		
43.		Socket screw	2	M4x6L	
44.		Socket screw	2	M5x8L	
45.	100217	Setting nut	1		
46.	100232	Adjusting handle	1		
47.					
48.					

SPINDLE



A:618AH/AHD

SPINDLE


B:818AHD

NO.	PART NO.	DESCRIPTION	Q'TY	SPECIFICATION	REMARKS
1.	100127	Lock screw	1		
2.		Retaining ring	1	E8	
3.	100125	Wheel guard door	1		
4.	100115	Nut	1		
5.	100117-1	Wheel setting nut	1		
6.	100116-1	Washer	1		
7.	100131	Grinding wheel	1		
8.	100113	Wheel hub	1		
9.	100119	Balance block	3		
10.		Steel ball	3	ø4	
11.		Socket screw	3	M5 x 6L	
12.	100126	Wheel guard	1		
13.		Bolt	1	M8x8L	
14.		Headless screw	2	M5x6L	
15.	100110	Setting nut	1		
16.	100108	O-ring	1		
17.	100109	Pressing plate	1		
18.		Ball bearing	1	#7006C	
19.	100104	Bearing washer	1		
20.	100105	Bearing washer	1		
21.		Ball bearing	1	#7006C	
22.	100102 211002	Spindle	1		A B
23.		Ball bearing	1	#7204C	
24.	100106	Bearing washer	1		

SPINDLE

NO.	PART NO.	DESCRIPTION	Q'TY	SPECIFICATION	REMARKS
25.	100107	Bearing washer	1		
26.		Ball bearing	1	#7204C	
27.	100111	Setting nut	1		
28.		Headless screw	2	M6 x 8L	
29.		Hex. screw	6	M6 x 30L	
30.	100103 211003	Spindle housing	1		A B
31.	100112	Rear cover	1		
32.	100120	Coupling	1		
33.		Pin	1	6x6x15L	
34.	100121-1	Rubber coupling	1		
35.		Socket screw	2	M6 x 8L	
36.		Socket screw	6	M6 x 12L	
37.	100101 211001	Headstock	1		A B
38.	100123	Bushing	1		
39.		Screw	4	M4x12L	
40.	100120	Coupling	1		
41.		Setting key	1	6x6x15L	
42.		Socket screw	2	M8 x 8L	
43.		Socket screw	6	M8 x 25L	
44.	100122A 100122B	Motor support	1		A B
45.		Inner hex screw Outer hex screw	4	M10 x 35L	1.5HP 2.0HP
46.		Socket screw	3	M6 x 30L	
47.	100124 211004	Motor	1	1.5HP 2.0HP	
48.		Round head screw	4	M6x16L	

AUTO ELEVATING MECHANISM (618AHD)
818AHD




AUTO ELEVATING MECHANISM

618AHD
(818AHD)

1.		Hex screw	4	M6x20L	
2.	200209-1	Motor	1		
3.		Hex screw	4	M6x25L	
4.		Washer	4	∅6	
5.	200208-1 200208A-1	Motor support	1		AHD
6.		Cross head screw	2	M6 x 10L	
7.	200219	Safety cover	1		
8.	200202-1	Moto supporter	1		
9.		Inner hex screw	4	M5 x 8L	618 818 AHD
10.	200215	Coupling	1		"
11.	100121-1	Rubber coupling	1		"
12.	200214	Coupling	1		"
13.		Hex screw	4	M6 x 16L	"
14.	200218	Stepping motor	1		"
15.	200208-1	Motor support	1		"
16.		Hex screw	4	M6 x 25L	"
17.	200211	Ring washer	2		
18.	200207-1 200207A-1	Timing belt pully (small)	1		618,818AHD
19.	200203-1 200203A-1	Safety cover	1		"
20.		Cross head screw	4	M5 x 10L	
21.	200204	Switch box	1		618 818 AHD
22.		Cross head screw	2	M6x30L	"
23.		Hex screw	3	M6x25L	
24.		Inner hex screw	1	M8x20L	

25.		Inner hex screw	2	M5x16L	618 818AHD
26.	200213	Switch bracket	1		"
27.	220212	"	1		"
28.		Cross head screw	1	M5x8L	"
29.		Proximity switch	1	TL-B5NE1	"
30.		Cross head screw	2	M5x25L	"
31.		Hexagonal nut	1	M8	"
32.	200316	Pressing bar of belt	1		"
33.		Hex screw	1	M6x20L	"
34.		"	1	M4 x 10L	"
35.		Spring	1		"
36.	100409	Bushing	1		"
37.		Needle bearing	2	DHK-1212	"
38.	100408-1	Gear shaft	1		"
39.		Inner hex screw	2	M5 x 8L	
40.		"	2	"	
41.	200210	Timing belt	1		
42.	200206	Timing belt pully	1		
43.	100215 100216	Index disc	1	MM INCH	
44.		Hex screw	1	M4 x 6L	
45.	100218	Bolt	1		
46.		Cross head screw	2	M4 x 8L	
47.		Washer	2	φ4	
48.	200205	Hand wheel	1		

ELECTRICAL BOX (618 AHD.)
(818 AHD.)





ELECTRIC DIAGRAM

MODEL: **Supra** **618AH**
 618AH/818AHD


INDEX

PAGE


1. ELECTRIC DIAGRAM OF 618 AH..... 63
2. ELECTRIC DIAGRAM OF 618/818 AHD..... 69




MODEL:618AH




Not this model




MODEL: 618AH




MODEL: 618AH



MODEL: 618AH




CONTROL STATION





CONTROL STATION
BACK VIEW



CONTROL PANEL




MODEL:618AH




MODEL:
618/818AHD




MODEL:
 618/818AHD



MODEL:
618/818AHD



MODEL:
618/818AHD



MODEL :
618/818AHD

