

ACER Group

Springwood Industrial, Inc.
2320 E Valencia Dr
Fullerton, CA 92831
Tel: 714-871-5558 Fax: 714-871-5554
<http://www.aceronline.net>

info@aceronline.net

Klim Industrial, Inc.
244 N. Randolphville Road
Piscataway, NJ 08854
Tel: 732-752-9100 Fax: 732-752-9101
<http://www.aceronline.net>

acer_klim@yahoo.com

HOW TO ADJUST THE OVERLOAD CLUTCH ON THE DYNAMIC-1440G

1. Slightly tighten the 4 screws on the Safety Assembly. Do not tighten too much or there is not safety overload.

