

Springwood Industrial, Inc.  
2320 E Valencia Dr  
Fullerton, CA 92831  
Tel: 714-871-5558 Fax: 714-871-5554  
<http://www.aceronline.net>

[info@aceronline.net](mailto:info@aceronline.net)

Klim Industrial, Inc.  
244 N. Randolphville Road  
Piscataway, NJ 08854  
Tel: 732-752-9100 Fax: 732-752-9101  
<http://www.aceronline.net>

[acer\\_klim@yahoo.com](mailto:acer_klim@yahoo.com)

## HOW TO REVERSE SPINDLE ROTATION ON E-LATHE 17" LATHE

1. To reverse spindle rotation on the E-Lathe 17" Lathe, reverse #4 & #5 wires.

