





**Please unscrew 4 screws
and remove the cover.**

**Rapid Up-Down Clutch
Adjustment**





Transmission Base

Check that Clutch B is secure on the Transmission Base.

Check Clutch A has close contact on Clutch B & lock the set screw tightly.

Clutch B

Set Screw

Electro Magneitc Clutch Base

