

# **Coolant Volume for Coolant Thru Spindle Tank**

**Fill up Coolant Thru Spindle Tank to around 65 gallons.**

**Fill machine main tank to 75 gallons (80%). If too much coolant is filled on both tanks, it will cause the coolant to flow onto the floor.**