


Procedure to Check for Electric Auto Parallel Dresser



1. (Circle 1) Please check if the power light is on or off. If no light, then there is no power input. Please check the T5.R7 to see if it AC12V input.
2. (Circle 2) Push the Slow Up and Down button. Red, White, Green light will light. The Green is the Forward/Reverse light. The White light turns Red, it means its is activated. The Red is the Stepping Motor hold function light.
3. (Circle 3) The 4th light. Hold the Stepping Motor light.



See if to check AB light will be on when you push on/off switch.