


PROCEDURE TO INSTALL SCALE ON 3VKH E-MILL



1. Install reader head bracket. Use a spacer if necessary.



2. Use indicator to align the reader head.



3. Insert scale.

4. Install both sides of the holding bracket.



Left




Right



5. After you install the holding bracket, take out the holding bracket and install the chip cover and reinstall the holding bracket. Make sure everything is level (holding bracket and reader head.)



6. Use indicator to align reader head for table.





It should look like this:

