



Springwood Industrial, Inc.  
1062 N. Kraemer Place  
Anaheim, CA 92806  
Tel: 714-632-9701 Fax: 714-632-9730  
<http://www.acergroup.com>

[info@acergroup.com](mailto:info@acergroup.com)

Klim Industrial, Inc.  
244 N. Randolphville Road  
Piscataway, NJ 08854  
Tel: 732-752-9100 Fax: 732-752-9101  
<http://www.acergroup.com>

[acer\\_klim@yahoo.com](mailto:acer_klim@yahoo.com)

## FANUC OiMC CONTROL FILE MANAGEMENT

### PROCEDURE TO DELETE FILE FROM MEMORY CARD

#### Start in Edit Mode

1. Press “PROG” to display file
2. Press “DIR” (Program Directory)
3. Press “+”
4. Press “CARD”
5. Press “OPRT”
6. Press “DELETE”
7. To delete a file, type the File No. For example, type “4”.
8. Press “F SET”
9. Press “EXEC”

### PROCEDURE TO COPY CNC FILE TO MEMORY CARD

#### Start in Edit Mode

1. Press “PROG” to display file
2. Press “DIR” (Program Directory)
3. To copy a file, type the File No. For example, type “13”
4. Press “O SRH”
5. Press “OPTR”
6. Press “+”
7. Press “PUNCH”
8. Press “EXEC”

## PROCEDURE TO DELETE FILE FROM CNC CONTROL

Start in Edit Mode

1. Press “PROG” to display file
2. Press “DIR” (Program Directory)
3. To delete a file, type the File No. For example, type “6768” (O file)
4. Press the “Delete” key



## PROCEDURE TO TRANSFER A FILE FROM THE MEMORY CARD TO THE CNC CONTROL

Start in Edit Mode

1. Press “PROG” to display file
2. Press “+”
3. Press “CARD”
4. Press “OPRT”
5. Press “F READ”
6. To transfer a file, type the File No. For example, type “4”
7. Press “F SET”
8. Type a new name for the file being transferred, for example, “1234”
9. Press “O SET”
10. Press “EXEC”